



SEA[®]

Automatic Gate Openers

International registered trademark n. 804888


CE UK
CA

ENGLISH


UNIGATE

UNIGATE INVERTER


(1I - 2I - 1I BIG - 2I BIG)




UNIGATE 2PM - 4PM



UNIGATE 24V



UNIGATE BR (36V)



SEA S.p.A.

Zona Industriale Sant'Atto - 64100 - Teramo - ITALY

Telephone: + 39 0 861 588341

www.seateam.com

INDEX

PRELIMINARY INFORMATION AND PRODUCT DETAILS	4
1 - CONNECTIONS ON THE «UNILOGIC» BASIC MODULE	
OVERVIEW OF THE TERMINALS ON THE MAIN MODULE	8
2 - CONNECTIONS ON CN1	
START, STOP BUTTONS, PHOTOCELLS, 24VAUX OUTPUT OPTIONS, TIMER	9
FLASHING LIGHT, SAFETY EDGE, 10K PHOTOCELLS AND BUZZER	10
MAGNETIC LOOP, «LATCH» BUTTONS, «FIRE SWITCH» FUNCTION, EXTERNAL RECEIVER	11
3 - CONNECTIONS ON CN2	
LIMIT SWITCH, ELECTRIC LOCK, 24VDC OUTPUT OPTIONS AND COMMON ACCESSORIES «COMIS»	12
4 - CONNECTIONS ON CN3	
STANDARD ENCODER AND ITS MANAGEMENT; POTENTIOMETER AND «RT» ENCODER CONNECTIONS	13
POTENTIOMETER/«RT» ENCODER CONFIGURATION AND PARAMETERS	14
PROGRAMMABLE INPUTS «GP1» AND «GP2», TEMPERATURE PROBE, «CAGE» FUNCTION	15
5 - SPECIAL CONNECTIONS ON CN2 and CN3	
LIMIT SWITCH SPECIAL CONNECTIONS ON «FV» INVERTER MODULE OR «2PM» MODULE	16
LIMIT SWITCH SPECIAL CONNECTIONS ON «2PM» MODULE - <i>STARTING FROM FIRMWARE REVISION 03.03</i>	17
6 - CONNECTIONS ON CLS - PLUG-IN LIMIT SWITCH	
LIMIT SWITCH QUICK CONNECTOR FOR SLIDING OPERATORS	18
7 - CONNECTIONS ON CR1 and CR2 (DRY CONTACT RELAY)	
MANAGEMENT OF ACCESSORIES CONNECTED VIA RELAY: COURTESY LIGHT, VERTICAL LOCK	18
MEGNETIC LOCK, ELECTRIC VALVE, TRAFFIC LIGHT	19
8 - CONNECTIONS ON P/S - PRIMARY/SECONDARY OPERATION (MASTER / SLAVE)	
CIRCUIT CONNECTION AND CONFIGURATION OF THE PRIMARY/SECONDARY OPERATION	20
9 - CONNECTIONS ON EXP - EXTERNAL MODULES	
«RS485» CIRCUIT, «SEM2» CIRCUIT, «UNIREG» CIRCUIT	21
10 - MOTORS WIRINGS ON THE DIFFERENT MODULES	
CONNECTION ON «FV» MODULE, ELECTRIC-BRAKE CONNECTION, THREE-PHASE CONNECTION	22
CONNECTION ON «2PM» MODULE, ON «24V» MODULE, ON «BR» MODULE, «ABC» ENCODER	23
11 - POWER SUPPLY	
UNILOGIC POWER SUPPLY, «FV» MODULE POWER SUPPLY, «2PM» MODULE POWER SUPPLY	24
«24V» MODULE POWER SUPPLY, «BR» MODULE POWER SUPPLY	25
12 - CONNECTIONS ON CNB - EMERGENCY BATTERIES CONNECTIONS	
UPS ON «FV» AND «2PM» MODULES, EMERGENCY BATTERIES ON «24V» AND «BR» MODULES	26

INDEX

13 - RECEIVERS CONNECTION ON CNR AND FIX

CONNECTION OF THE PLUG-IN RECEIVERS	27
---	----

14 - ADDITIONAL FUNCTIONS OF THE CONTROL UNIT

DATE/TIME FUNCTION AND CLOCK FUNCTION TO MANAGE PROGRAMMED OPENINGS	27
MANAGEMENT AND CONFIGURATION OF THE AMPEROMETRIC FUNCTION	28
«SURGE PROTECTOR» CIRCUIT CONNECTION, E.F.O. FUNCTION FOR BOLLARDS	29

15 - DISPLAY OPERATION AND PROGRAMMING MENU

UNIT SWITCHING ON, DISPLAY READING, BASIC MENU AND SPECIAL MENU	30
---	----

16 - BASIC MENU

BASIC MENU DIAGRAM AND OPERATION	31
--	----

17 - INPUTS STATUS MANAGEMENT

READING OF THE <i>N.C.</i> OR <i>N.O.</i> STATUS OF THE INPUTS ON THE DISPLAY	32
DIAGRAM AND OPERATION OF THE INPUTS MANAGEMENT MENU	33

18 - WORKING TIMES LEARNING - *PROGRAMMING OF THE CONTROL UNIT*

PRELIMINARY SETTINGS, ENCODERS OR POTENTIOMETER ACTIVATION	34
QUICK LEARNING FOR SLIDING OPERATORS, WORKING TIMES LEARNING WITH LIMIT SWITCH	35
WORKING TIMES LEARNING WITH THE DIFFERENT MODELS OF ENCODER OR POTENTIOMETER	36
MANUAL WORKING TIMES LEARNING WITH «RT» ENCODER OR «RS 485» ENCODER	37
WORKING TIMES LEARNING BY MANUAL PULSES, OR BY PULSES WITH POTENTIOMETER	38

19 - OPERATING LOGICS

SEMI-AUTOMATIC, AUTOMATIC, SAFETY, STEP-BY-STEP 1 AND 2, DEAD MAN, 2 BUTTONS	39
--	----

20 - PASSWORD - *PROTECTION OF THE CONTROL UNIT BY PASSWORD*

PASSWORD ENTRY PROCEDURE	39
--------------------------------	----

21 - RECEIVERS AND TRANSMITTERS - *PROGRAMMING OF THE TX*

«ROLLING CODE», «ROLLING CODE PLUS», «UNI», «FIX CODE» TRANSMITTERS	40
DIAGRAM OF THE AVAILABLE FUNCTIONS FOR TRANSMITTERS	41

22 - ALARMS AND FAULTS WARNINGS - *VIA DISPLAY OR FLASHING LIGHT*

LIST OF FAULTS SHOWN ON THE DISPLAY, NUMERICAL ERROR CODES	42
LIST OF FAULTS INDICATED BY FLASHING LIGHT, DIAGNOSTICS MENU	43

23 - TROUBLESHOOTING

MOST FREQUENT PROBLEMS AND SOLUTIONS	44
--	----

MENU TABLE

46

PRELIMINARY

● **UNIGATE** is a modular electronic control unit, for the management of different types of operators and different applications thanks to the additional modules, which transform the unit into the model best suited to the various management needs

● The main module, common to all models, is the «**UNILOGIC**» module, which allows the connection and management of accessories, logics, and all board functions

⇒ **The combination of each add-on module requires a specific firmware on the UNILOGIC main module!**

● **The UNIGATE control unit requires the programming of the working times (chapter 18);** it is not possible to start the operator correctly without first programming the control unit!

● The unit and the accessories programming and settings can be carried out by the display on board or by the **JOLLY 3** programmer or **SEACLOUD**



● Functions and menus here described are valid only for the below listed software revisions; if some functions or menus do not correspond to your control unit, consult the previous manuals

MODEL	SOFTWARE REVISION	MODEL	SOFTWARE REVISION
UNIGATE FV (INVERTER)	03.19	UNIGATE 24V	00.04
UNIGATE 2PM	03.03	UNIGATE BR	03.02




All wirings (circuits and accessories) must be made when the **control unit is OFF and not powered**; only after completing all wirings the control unit can be switched-on and programmed

TECHNICAL INFORMATION

POWER SUPPLY	ABSORPTION IN STAND-BY	OPERATING TEMPERATURE	PROTECTION CLASS OF THE PLASTIC BOX (IF INCLUDED)
230VAC - 50/60 Hz OR 115VAC - 50/60 Hz	30 mA	-20° C / +50° C	IP 55

RESET PROCEDURE




NOTE FOR THE INSTALLER: the list of spare parts for «UNIGATE» control units is available inside the reserved area of the SEA website: www.seateam.com

UNIGATE INVERTER - «FV» MODULE


UNIGATE INVERTER 1I

MANAGEMENT OF 1 OPERATOR WITH INVERTER




UNIGATE INVERTER 2I

MANAGEMENT OF 2 OPERATORS WITH INVERTER




UNIGATE INVERTER 1I-BIG

MANAGEMENT OF 1 «BIG» OPERATOR WITH INVERTER





UNIGATE INVERTER 2I-BIG

MANAGEMENT OF 2 «BIG» OPERATORS WITH INVERTER




WIRINGS ON «FV» MODULE



USB CONNECTOR
TO «UNILOGIC»



DO NOT CONNECT CAPACITORS!




The components are also valid for «FV-BIG» MODULE

IT IS MANDATORY TO CONNECT THE GROUND CABLE - DO NOT CONNECT THE CAPACITORS!

UNIGATE 2PM / 4PM - «2PM» MODULE


UNIGATE 2PM

2 OPERATORS MANAGEMENT





UNIGATE 4PM

4 OPERATORS MANAGEMENT




WIRINGS ON «2PM» MODULE




UNIGATE 24V - «24V» MODULE

UNIGATE 24V

1 or 2 24V OPERATORS MANAGEMENT




WIRINGS ON «24V» MODULE



UNIGATE BR - «BR» MODULE


UNIGATE BR

1 BRUSHLESS OPERATOR MANAGEMENT





UNIGATE 2BR

2 BRUSHLESS OPERATORS MANAGEMENT




WIRINGS ON «BR» MODULE




1 - CONNECTIONS ON «UNILOGIC» MODULE

 **Make all the wirings when the control unit is not powered!**
Keep the power cables separate from the command cables - always run cables in separate sheaths to prevent interferences!




- AUTOMATIC RECOGNITION OF THE N.C. INPUTS NOT IN USE - NO JUMPERS REQUIRED ON THE N.C. CONTACTS
- TO RESTORE THE EXCLUDED INPUTS USE THE «**INPUTS MANAGEMENT**» MENU (*CHAP. 17*) - NO NEED TO SET UP THE UNIT AGAIN



* All the 24V outputs (**24VAUX on CN1 - 24VDC(+) on CN2 - 24V(+) on CN3**) support a maximum load of 1A referred to the sum of the loads of all 24V accessories connected, including the absorption of the receiver on board (30 mA)

2 - CONNECTIONS ON CN1



2.1 - START (N.O.)

- Connect the «START» command on clamps 3 and 6
- Logics to be linked to the «START» command: **chapter 19**

⇒ If the input is engaged during the pause time, the gate does not close until the input is released

2.2 - PARTIAL START (N.O.)

- Connect the «PARTIAL START» command on clamps 4 and 6
- Logics to be linked to the «PARTIAL START»: **see chapter 19**

Partial opening space management:

90
PARTIAL
OPENING

Partial opening pause time management:

91
PARTIAL
PAUSE

⇒ If the input is engaged during the pause time, the gate does not close until the input is released

i If a **traffic light** is connected it is possible to enable the entry or the exit priority linked to the «START» or the «PARTIAL START» commands, via menu 89

89
TRAFFIC LIGHT
RESERVATION

2.3 - STOP (N.C.)

- Connect the «STOP» command on the clamps 5 and 6
- After stopping, press «START» to restore the movement

⇒ The operator starts-up in closing after a «STOP» command; In case of «BR» module, it starts-up in the same direction.

2.4 - PHOTOCELL 1 AND PHOTOCELL 2 (N.C.)

- Wirings: + = 24V \Rightarrow max 1A (CLAMP 19 on CN2)
PH1 = Photocell 1 (CLAMP 7)

COM = 0V (COMMON CLAMPS)
PH2 = Photocell 2 (CLAMP 8)

- Management and settings:

97
PHOTOCELL
1

98
PHOTOCELL
2

- «FOTOTEST» function: Connect the Tx-photocell positive cable on clamp 12 and chose the photocell to be tested on menu 95

⇒ Default settings: **97** = «CLOSING»; **98** = «OPENING AND CLOSING»

⇒ The use of **SHIELDED PHOTOCELLS** IS MANDATORY !

95
PHOTOTEST

2.5 - 24V \Rightarrow DC AUX OPTIONS - MAX 1A - CLAMP 12

- Management: choose how and when to have voltage on the AUX output on menu 94 according to the type of accessory you wish to connect

94
24V AUX

- A relay can be connected to the 24VAUX output; the relay allows the connection and management of additional accessories (courtesy light, etc.)

2.6 - TIMER (N.O.) - EXTERNAL CLOCK


92
TIMER

- Connect the timer to the clamp 4 «PARTIAL START» or to the clamp 8 «PHOTOCELL 2»
- If wired to the «PARTIAL START», this command will be disabled (on transmitters too)
- The timer opens and keeps the gate open until engaged; when released, the gate closes only after the pre-set pause time has elapsed
- In the event of a safety accessory intervention, the timer automatically resets after 6 sec.

⇒ In the event of a power failure when the gate is open:

if the **TIMER** is still active when the power is restored, the gate remains open;
if the **TIMER** is no longer active, a «START» input will be required to close the gate

FLASHING LAMP AND SAFETY EDGE



2.7 - 24V \equiv FLASHING LIGHT - MAX 3W

- Wirings on clamps 13 and 19 on CN2 (or 30 on CN3)
- Gate movement signals:
 - 1 BLINK/SECOND IN OPENING
 - 2 BLINKS/SECOND IN CLOSING
 - STEADY LIT DURING PAUSE

86
FLASHING
LIGHT

- Operation mode management: menu 86
- Pre-flashing mode management: menu 85

85
PRE-
FLASHING

⇒ The control unit sends the warning signals even through the flashing lamp; see **chapter 22 «ALARMS»**

2.8 - SAFETY EDGE (N.C.)

- Connect the safety edge 1 on clamps 9 and 11
- Connect the safety edge 2 on clamps 10 and 11
- Safety edges management: choice of the edge type - menu 100-101
- Direction management: choice of the desired direction - menu 102-103

100
SAFETY
EDGE 1

101
SAFETY
EDGE 2


102
EDGE 1
DIRECTION

103
EDGE 2
DIRECTION

⇒ Balanced or 8K2 resistive safety edge (single or double):
contact checking through resistance value
to detect short-circuits (with alarm on display)




PHOTOCELLS 10K



2.9 - 10K PHOTOCELL SINGLE OR DOUBLE

- Connect to clamps 7 and 8 on CN1 - 19 on CN2 and COM (6 - 11 - 16)
- Up to two 10K photocells (or up to four with «UNIGATE 2PM») can be connected; set the menus 121 or 122 on «SINGLE» or «DOUBLE»



- The desired operation mode can be set on the menus «PHOTOCELL»


97
PHOTOCELL
1

98
PHOTOCELL
2

⇒ By the use of the 10K photocells, a further protection is given, even in the event of a short-circuit on the cables

2.10 - BUZZER 24V \equiv

- Connect the buzzer on clamp 13 on CN1 and 19 on CN2
- Use a 24V \equiv and 100 dB oscillating Buzzer
- The Buzzer can be connected instead of the flashing light; however, it is necessary to set the menu as «BUZZER»





- The Buzzer activates after 2 consecutive interventions of the anti-crushing protection

⇒ Press the STOP button to turn off the buzzer; anyway, the sound switches off automatically after 5 minutes and the operator remains stopped waiting for a new command

⇒ **IF THE BUZZER DOES NOT RUN, MAKE SURE THAT THE MENU 86-FLASHING LIGHT IS SET ON «BUZZER»**


BUZZER





2.11 - SAFETY LOOP

- **FREE EXIT LOOP (LOOP 1)**
3 = START (N.O.)
6 = COMMON
- **REVERSE LOOP (LOOP 2)**
7 = PHOTOCELL 1 (N.C.)
6 = COMMON
- **SHADOW LOOP (LOOP 3)**
8 = PHOTOCELL 2 (N.C.)
6 = COMMON



➔ **USE THE SAFETY LOOP COMBINED WITH THE «ULTRA LOOP PLUG» (23105142)**

2.12 - LATCH OPENING OR LATCH CLOSING BUTTON





- Connect one or two buttons to use as LATCH command on clamps 9 and 6 or on clamps 10 and 6



THE SAFETY EDGE FUNCTION WILL BE DISABLED


- Management: set the desired operation mode on the menu 118
- To disable the Latch function, press again the activation command

➔ *The LATCH command can also be sent from SEACLOUD or enabled on the second channel of the transmitter (paragraph 21.4), thus keeping the SAFETY EDGE input free;*




2.13 - «FIRE SWITCH» FUNCTION

- The emergency fire-switch can be connected on the «PARTIAL START» or the «PHOTOCELL 2» inputs
- The fire-switch operates in «DEAD MAN» mode and it disables all the safety devices when in use; The button only allows a complete opening (even when connected to the «PARTIAL START»)
- To close, first give a «STOP» command followed by a «START» command
- The «FIRE SWITCH» function can be enabled by the menu 93



2.14 - EXTERNAL RECEIVER

By wiring the 24V cable on the 19 (24V+) output on CN2 (rather than the clamp 12 on CN1) a continuous power supply is guaranteed to the receiver, leaving the 24VAUX output free for other accessories wirings.



3 - CONNECTIONS ON CN2

3.1 - LIMIT SWITCH

- Connect the opening and closing limit switch as shown


➔ The type of limit switch is automatically detected during the working times learning

ANTI-INTRUSION FUNCTION:

This function is linked to the limit switch activation; If enabled via the menu 79, this function restores the original position of the gate after a manual forcing or a blast of wind




IN CASE OF SINGLE LEAF, ONLY WIRE THE MOTOR 1 LIMIT SWITCHES; DO NOT JUMPER MOTOR2 LIMIT SWITCHES!



- ➔ To connect the limit switch of the sliding operators, use the special CLS quick connector
- ➔ To connect the limit switches of the BOLLARDS or hydraulic operators with 4 standard limit switches, see paragraph 5.1
- ➔ To connect the limit switches with UNIGATE 2PM or 4PM, see paragraphs 5.2 or 5.3 according to the firmware revision

3.2 - 12V ELECTRIC LOCK




- 12V and Max 15W electric lock wirings on outputs 21 and 22

- The lock activation mode can be adjusted by the menu 78


- The lock release time can be adjusted by the menu 77

The «**PUSHING STROKE**» function simplifies the lock release by giving a little pushing stroke before starting the movement



(EXAMPLES OF SETTINGS)


3.3 - 24VDC (+) OUTPUT



- 24VDC (+)** output (19) on CN2 to connect those 24V accessories which must always be active (example: external receiver)

➔ By connecting the common cable of the accessories on the input 20-«COMIS», the consumption can be measured. See next paragraph


3.4 - «COMIS» INPUT



- The **20-COMIS** input on CN2 allows to wire the common cable of the 24V accessories (**up to a max. load of 350 mA**) in order to measure their absorption

- The accessory absorption can be displayed by accessing the menu 137

- The «COMIS» input also allows the setting of a max. absorption threshold by the menu 138





(EXAMPLES)

The excessive absorption or short circuits are reported on the display («COMIS FAULT» - see alarm tables on **chapter 22**)

4 - CONNECTIONS ON CN3

4.1 - STANDARD ENCODER


- Connect one or two **ENCODERS** on CN3; respect the cable colors:
- To enable **ENCODER** - menu 32:



➡ To wire the «**ABC**» **ENCODER** to the «**BR**» module, follow the instructions on **paragraph 10.5**.
To wire the **RS 485 ENCODER**, follow the instructions on **paragraph 9.1**

- The menu 47 or 49 show the impulses read during the operation
- The menu 48 or 50 show the total pulses stored during the learning

➡ **The menus 47-48-49-50 are visible only when the menu 32 is «ON»**




➡ The Example refers only to **MOTOR 1 (M1)**; For **MOTOR 2 (M2)** parameters go to the menus 49 and 50


4.2 - ENCODER PARAMETERS ADJUSTMENT

- Settable values: minimum 10% (rapid intervention) - maximum 99% (slow intervention)
- ➡ **If set to OFF (intervention excluded), the encoder only detects position**

- Opening intervention time adjustment




- Closing intervention time adjustment





➡ The Example refers only to **MOTOR 1 (M1)**; For **MOTOR 2 (M2)** parameters go to the menus 35 and 36


4.3 - «POSITION GATE» LINEAR POTENTIOMETER or «RT» ABSOLUTE ENCODER



- To enable the linear potentiometer:



- To enable the «RT» absolute encoder:



➡ **MANDATORY!** use of a 3-pole shielded cable! - wire the shield on the common clamp (25 or 29)


4.4 - LINEAR POTENTIOMETER or «RT» ABSOLUTE ENCODER CONFIGURATION

➔ The menus 51-52-53-54-55-56 are visible only when the menu 32 is set to «POSITION GATE» or ENCODER «RT»


● Motor 1 (menu 51) or motor 2 (menu 54) partial impulses; display of the operator current position



● Motor 1 (menu 52) or motor 2 (menu 55) impulses in opening; display of the impulses when the leaf is completely open; possibility to increase or decrease the total pulses



● Motor 1 (menu 53) or motor 2 (menu 56) impulses in closing; display of the impulses when the leaf is completely closed; possibility to increase or decrease the total pulses



4.5 - POTENTIOMETER or «RT» ENCODER PARAMETERS ADJUSTMENT

● Sensitivity parameters in opening and closing (Motor 1 and Motor 2) for potentiometer intervention time adjustment


➔ For a quick reverse on obstacle decrease the sensitivity



 Set to OFF (intervention excluded): merely detection of the impulses (does not reverse on obstacle)


● Slowdown sensitivity menu to adjust the inversion time during the slow down

➔ For a quick reverse on obstacle decrease the sensitivity




● To adjust the Encoder intervention threshold values in opening and closing (Motor 1 and Motor 2)

➔ The lower the threshold, the greater the force required for the inversion



● To adjust the threshold values for the Encoder intervention during the slow down, in opening and closing (Motor 1 and Motor 2)

➔ The lower the threshold, the greater the force required for the inversion




4.6 - ACCESS TO THE HIDDEN «DEBUG» MENU

● Display of the instantaneous speed values detected «VP1» and «VP2» (motor 1 and motor 2) to adjust the thresholds above described (thresholds must always be lower than the values shown in VP1 or VP2)



4.7 - «GP1» and «GP2» PROGRAMMABLE INPUTS



GP1 (27) = PROGRAMMABLE INPUT 1
GP2 (28) = PROGRAMMABLE INPUT 2



• «GP1» and «GP2» are two programmable inputs for additional accessories wiring (e.g. buttons or temperature probes) which require the specific settings given by menus 130 or 131

130
GP1

131
GP2

4.8 - TEMPERATURE PROBE


- Connect the temperature probe on «GP1»; in case of two probes, also use the contact «GP2»
- The probe detects the oil temperature; If it falls below the set threshold, the probe activates the heating, returning the values to the established range



➔ Screw the TEMPERATURE PROBE (or PROBES, in case of TWO operators) to replace the oil cap

4.9 - ACTIVATION AND SETTING OF THE TEMPERATURE PROBE


- To enable the probes: menu 130 and 131



- To display the DETECTED TEMPERATURE access the menu 109 (in case of two probes, both temperatures detected by each probe will be displayed)




- Setting of the HIGH and LOW TEMPERATURE THRESHOLDS, to enable or disable the oil heating




4.10 - «CAGE» FUNCTION ON MENU «GP1» and «GP2»

- Connect two «START» buttons on CN3
ON GP1 (CLAMP 27) AND COM (CLAMP 29)
ON GP2 (CLAMP 28) AND COM (CLAMP 29)



- «CAGE» function activation (menu 130 or 131)



- The function allows M1 and M2 opening and closing in «DEAD MAN» mode, as follows:
THE BUTTON WIRED TO GP1 OPENS M1 ONLY IF M2 IS COMPLETELY CLOSED
THE BUTTON WIRED TO GP2 OPENS M2 ONLY IF M1 IS COMPLETELY CLOSED



➔ THE «CAGE» FUNCTION IS AVAILABLE ONLY FOR «FV» MODULE - UNIGATE INVERTER

5 - SPECIAL WIRINGS ON CN2 and CN3

5.1 - SPECIAL WIRINGS FOR LIMIT SWITCHES with «FV» INVERTER MODULE

! WIRINGS VALID ONLY FOR BOLLARDS OR HYDRAULIC OPERATORS WITH 4 LIMIT SWITCHES AND ONLY FOR «UNIGATE FV INVERTER» CONTROL UNIT


● **ENABLE THE SLOWDOWN LIMIT SWITCHES BEFORE WIRING!**



5.2 - LIMIT SWITCHES SPECIAL WIRINGS with «2PM» or «4PM» MODULE - up to Rev. 03.02

! JUST FOR «UNIGATE 4PM» UP TO FIRMWARE REVISION 03.02 - FOR LATER REVISIONS, SEE PARAGRAPH 5.3

● In case of operators connected via «2PM» or «4PM» MODULES (for example one or more bollards), wire the limit switches according to the following diagrams:




5.3 - LIMIT SWITCHES SPECIAL WIRINGS with «2PM» or «4PM» MODULE - from Rev. 03.03




JUST FOR «UNIGATE 4PM» STARTING FROM FIRMWARE REVISION 03.03 - FOR PREVIOUS REVISIONS, SEE PARAGRAPH 5.2

- Connect the Motor 1 and Motor 2 limit switches to the CN2 connector, according to the diagram below;
- Connect Motor 3 and Motor 4 limit switches to the LSE circuit, *previously connected to the EXP connector of the «UNILOGIC»*, according to the following diagrams:



- If the limit switches of Motor 3 and Motor 4 are connected, their input status (if N.O. or N.C.) will be displayed in the positions shown on the side.


See also chapter 17



6 - CONNECTION ON CLS

6.1 - LIMIT SWITCH ON «CLS» QUICK CONNECTOR

- Some **SEA SLIDING OPERATORS** are equipped with a pre-wired limit switch which must be connected on the CLS special terminal according to the drawing
- The control unit manages mechanic, inductive and magnetic limit switches
- The type of limit switch is automatically detected during the working times learning





7 - CONNECTIONS ON CR1 and CR2

7.1 - RELAY 1 and RELAY 2 MANAGEMENT

- To wire additional accessories (*lights, traffic lights etc*); management through menus **132** and **133**



⇒ Options include the «**COPY**» of other accessory management menus to allow the connection of more units via relay



! The 24V power supply for the accessories connected via Relay must be provided by an external power supply having suitable power

7.2 - COURTESY LIGHT VIA RELAY



- A courtesy light can be wired to the CR1 (or CR2) relay; Set the menu **132** (or **133**) to «**COURTESY LIGHT COPY**» so that the relay replicates the management settings given to the menu **88** (such as the courtesy light timing - from 0 to 240 seconds)



7.3 - VERTICAL LOCK VIA RELAY

! SET THE MENUS AS FOLLOWS BEFORE CONNECTING THE LOCK!

- A vertical lock can be wired to the Relay; Set the menu **132** (or **133**) to «**LOCK COPY**» so that the relay replicates the management settings given to the menu **78**





7.4 - MAGNETIC LOCK VIA RELAY

- A magnetic lock can be wired to CR1 or CR2
- Management via menu 132 (or 133)






**SET THE MENU AS FOLLOWS
BEFORE CONNECTING THE LOCK!**





7.5 - ELECTRIC VALVE VIA RELAY

- One or two electric valves can be wired via relay. The electric valve can work in OPENING or CLOSING
- Management of each electric valve operation (in opening or closing) via menus 132 or 133





7.6 - TRAFFIC LIGHT VIA RELAY

- One or two traffic lights (red/green) can be wired to the CR1 (or CR2) relay, to manage the priority in entry or in exit



- To enable the priority function IN ENTRY (via **START** command) or IN EXIT (via **PARTIAL START** command), set the menu 89 to «ON»



The 24V power supply for the accessories wired via Relay must be provided by an external power supply having suitable power

8 - CONNECTION ON P/S (only for «FV» and «BR» modules)

8.1 - «PRIMARY/SECONDARY» (MASTER/SLAVE) CIRCUITS

● PRIMARY/SECONDARY mode: to manage 2 operators (ex. opposite barriers or bollards) having each one its control unit

● Wire each «PRIMARY/SECONDARY» circuit to the P/S connector of each control unit


● Management via menu 105; set a control unit as «PRIMARY» and the other as «SECONDARY»

P/S
105
PRIMARY
SECONDARY

➔ Connect all accessories on the «PRIMARY» control unit. The «SECONDARY» control unit only allows the management of the following menus:

1-LANGUAGE	47-MOTOR 1 PARTIAL ENCODER	83-EXTRA TIME
3-MOTOR	48-MOTOR 1 TOTAL ENCODER	86-FLASHING LIGHT
5-REVERSE MOTOR	59-MOTOR 1 SLOWDOWN IN OPENING	88-COURTESY LIGHT
14-RESET	60-MOTOR 1 SLOWDOWN IN CLOSING	94-24V AUX (NO AUTOTEST FUNCTION)
17-MOTOR 1 OPENING SPEED	63-DECELERATION	104-SELECT LIMIT SWITCH
18-MOTOR 1 CLOSING SPEED	64-ACCELERATION	106-DIAGNOSTICS
21-M1 SLOWDOWN SPEED IN OPENING	65-MOTOR 1 OPENING TIME	112-PASSWORD
22-M1 SLOWDOWN SPEED IN CLOSING	66-MOTOR 1 CLOSING TIME	115-DECELERATION RAMP
28-MOTOR 1 OPENING TORQUE	70-POSITION RECOVERY IN OPENING	123 - 127 DATE & TIME MENUS
29-MOTOR 1 CLOSING TORQUE	71-POSITION RECOVERY IN CLOSING	130 - 135 RELAY MENUS
32-ENCODER	72-MOTOR 1 TOLERANCE IN OPENING	137-COMIS
33-MOTOR 1 OPENING SENSITIVITY	73-MOTOR 1 TOLERANCE IN CLOSING	140-M1 OPENING «A» THRESHOLD
34-MOTOR 1 CLOSING SENSITIVITY	76-PUSHING STROKE	141-M1 CLOSING «A» THRESHOLD
37-SLOWDOWN SENSITIVITY	78-LOCK	144-M1 OPENING SLOWDOWN «A» THRESHOLD
		145-M1 CLOSING SLOWDOWN «A» THRESHOLD

8.2 - «PRIMARY/SECONDARY» CONFIGURATION




* Install and set up the two operators as if they were two independent installations. check the correct functioning and the correct reading of the limit switches, if installed.

9 - CONNECTION ON EXP

9.1 - RS 485 CIRCUIT


- The **RS 485 CIRCUIT** manages one or two absolute rotative encoders type RS 485 for one or two operators.



- The «RS 485» encoder must be enabled on menu 32 **before** the working times learning; For the working times learning special procedure, see the **paragraph 18.8**



9.2 - «SEM 2» MANAGEMENT UNIT




- The SEM 2 accessories management unit allows you to connect and manage the following additional accessories:

- traffic light
- courtesy light
- vertical electric lock
- positive or negative electric brake

➔ **SEM2 READS THE LIMIT SWITCHES STATUS** (to connect those accessories whose activation depends on the limit switches status)

 **MORE DETAILS ON SEM 2 INSTRUCTIONS**

9.3 - «UNIREG» ANALOG MANAGEMENT UNIT




- The «UNIREG» analog management unit combined with the «UNILOGIC» allows the connection of one or two operators which can be programmed and managed via trimmers and dip-switches


 **MORE DETAILS ON UNIREG INSTRUCTIONS**

10 - MOTORS CONNECTION


10.1 - OPERATORS CONNECTION ON «FV» MODULE



- The «FV» module is equipped with a dry contact relay input (*max 5A*) for **additional accessories management; settings via menu 134 (and 135 in case of two FV modules)**



- On the «**BIG FAST**» and «**LEPUS INDUSTRIAL FAST**» operators, the electric brake must be connected via bridge rectifier to the relay and the power terminals




10.2 - THREE-PHASE POWER SUPPLY FOR «LEPUS THREE-PHASE 230V»


- LEPUS THREE-PHASE** operator requires connection via terminal block, as shown in the diagram

- If limit switches are installed on the operator, connect them as shown in the diagram

➡ If there is no correspondence between the motor movement direction and the respective limit switch, swap the limit switch cables




10.3 - OPERATORS CONNECTION ON «2PM» MODULE




- ➔ **UNIGATE 4PM: CONNECT THE OTHER TWO OPERATORS ON M1 AND M2 OF THE SECOND 2PM MODULE; DURING THE WORKING TIMES LEARNING, M1 AND M3 WILL MOVE TOGETHER, AS M2 AND M4 WILL**
- ➔ **LIMIT SWITCH WIRINGS to UNIGATE 2PM / 4PM: SEE THE PARAGRAPHS 5.2 OR 5.3**

10.4 - OPERATORS CONNECTION ON «24V» MODULE




10.5 - OPERATORS CONNECTION ON «BR» MODULE




- Types of connection of the «ABC» ENCODER on the «BR» (*brushless 36V*) operators

FREE WIRES CONNECTION ON CN5



PRE-WIRED CONNECTION ON CNE



11 - POWER SUPPLY CONNECTION ON «PW»




**FOR THE CONNECTION TO THE POWER GRID, RESPECT THE LAWS IN FORCE!
THE GROUND CABLE CONNECTION IS MANDATORY! WE RECOMMEND THE INSTALLATION OF
AN EARTH ROD FOR EXCLUSIVE USE OF THE CONTROL UNIT**

- ⇒ Fuse 3.15 AT delayed on 230V~ and 6.3 AT delayed on 115V~ power supply
- ⇒ Use a 10A differential switch to protect the power supply system
- ⇒ In case of unstable power supply, the use of an external UPS of min. 800VA is recommended


11.1 - «FV» MODULE POWER SUPPLY for «UNIGATE INVERTER»

- Connect the «FV» module to the «UNILOGIC» unit via USB connector
- Connect the «FV» module to the main power supply as shown below:





11.2 - «2PM» MODULE POWER SUPPLY

- Connect the «2PM» module to the «UNILOGIC» via USB connector and pre-wired cable
- Connect the «2PM» module to the main power supply as shown below:





11.3 - «24V» MODULE POWER SUPPLY

- Connect the «24V» module to the «UNILOGIC» unit via USB connector
- Connect the «24V» module to the main power supply via switching, as shown below:



11.4 - «BR» MODULE POWER SUPPLY

- Connect the «BR» module to the «UNILOGIC» unit via USB connector
- Connect the «BR» module to the main power supply via switching, as shown below:



12 - CONNECTION ON CNB



12.1 - «STAR 400/800» EMERGENCY UPS CONNECTION



The «STAR 400/800» emergency UPS can be used only when the «FV» module or the «2PM» module are connected to the UNILOGIC

● MANAGEMENT: **113**
EMERGENCY

● The unit controls the battery charge in order to perform a last opening or a last closing maneuver before the batteries are completely discharged




*** Notice for UPS wiring only:** disconnect the positive cable from the switching to the «PW» terminal and connect it on the «CNB» positive input


**MORE DETAILS ON
STAR 400/800 INSTRUCTIONS**

12.2 - EMERGENCY BATTERIES ON «UNIGATE BR»



ONLY FOR «BR» MODULE IN «R3» VERSION



12.3 - EMERGENCY BATTERIES ON «UNIGATE 24V»



13 - RECEIVERS CONNECTION ON CNR and FIX



RECEIVER MODEL	MAX USERS NUMBER
RF UNI	16 USERS - Without additional memory 800 USERS - With MEMO additional memory
RF UNI PG old model non-extractable memory	100 USERS - If programmed in FIX CODE 800 USERS - If programmed in ROLLING CODE PLUS
RF UNI PG new model extractable memory	496 USERS - If programmed in FIX CODE 800 USERS - If programmed in ROLLING CODE PLUS
RF FIX	16 USERS - Without additional memory


! *Respect the plug-in direction of the different receiver circuits;
The «ANT» contacts printed on the receiver and on the control unit must correspond!*

14 - ADDITIONAL FUNCTIONS

14.1 - CURRENT DATE/TIME SETTING


● To use the clock function, you must first set the current date and time (*function available only if the emergency batteries are connected and they are at full charge*)

Example



14.2 - CLOCK FUNCTION FOR PLANNED OPENING/CLOSING

! *TO USE THE CLOCK FUNCTION, YOU MUST FIRST
SET MENU 92 TO «CLOCK»*



● Setting of a day and a time slot to manage the planned openings and closings (**weekly setting**)



● Up to 4 time slots available (*one for each clock*) for each day you want to plan!



EXAMPLE CLOCK 1




EXAMPLE CLOCK 2



14.3 - AMPEROMETRIC MANAGEMENT - ONLY FOR 24V and «BR» ELECTROMECHANIC OPERATORS


- Obstacle detection system with inversion both in OPENING and CLOSING
- Set the menu 37 on a value different from OFF (which is set by default) to enable the function



→ the greater the value, the greater the amperometric intervention delay


- Torque parameters setting in opening and closing for adjustment of the inversion force on obstacle

→ the greater the torque, the greater the force required for the inversion



- Sensitivity parameters in opening and closing for the amperometric intervention time adjustment

→ for a quick reverse on obstacle decrease the sensitivity




i If set to OFF (intervention excluded) the amperometric management will only work according to the menu 37 settings

14.4 - ABSORPTION and AMPEROMETRIC THRESHOLDS

- Absorption control during the movement and during the amperometric intervention
- Amperometric intervention threshold adjustment in opening and closing

→ Beyond the established threshold value, the operator intervenes on any obstacle detected



! Set threshold values at least 10% higher than the read absorption values; Carry out impact tests to comply with safety regulations

14.5 - AMPEROMETRIC INTERVENTION METHOD

- It is possible to choose between TOTAL or PARTIAL reopening after the amperometric intervention in closing (menu 46)

→ When the menu 46 is set to «TOTAL» and the menu 7 is different from OFF, the «AUTOMATIC RECLOSING» function automatically enables: in case of obstacle the operator tries to reclose up to 5 times, then a new START command will be required to restore the motion.

→ In case of obstacle during the opening, the operator will always reverse partially!


i When the movement is restored after the partial inversion, the cycle will be performed at preset speed to detect the mechanical stops




14.6 - «I/O SURGE PROTECTOR» CIRCUIT

● To protect up to 6 inputs and the 24V power supply from temporary overloads (*ie. lightning strikes*)

● Connect the 24VDC cable and the accessories cables on **INPUT**; connect the corresponding cables from **OUTPUT** to the control unit

 **Connect the negative and the common cables from the main power supply to the control unit**



OUTPUT CONNECTION ON CONTROL UNIT

- | | |
|---|-----------------------------|
| 1 | 24V DC ACCESSORIES |
| 2 | CONTACT 1 (Es. PHOTOCELL) |
| 3 | CONTACT 2 (Es. SAFETY EDGE) |
| 4 | CONTACT 3 (Es. START) |
| 5 | CONTACT 4 |
| 6 | CONTACT 5 |
| 7 | CONTACT 6 |

INPUT ACCESSORIES CONNECTION




- | | |
|---|-----------------------------|
| 1 | 24V DC ACCESSORIES |
| 2 | CONTACT 1 (Es. PHOTOCELL) |
| 3 | CONTACT 2 (Es. SAFETY EDGE) |
| 4 | CONTACT 3 (Es. START) |
| 5 | CONTACT 4 |
| 6 | CONTACT 5 |
| 7 | CONTACT 6 |

14.7 - E.F.O. FUNCTION - ONLY FOR BOLLARDS MANAGED BY «UNIGATE FV» INVERTER

● The function allows the emergency closing at a higher speed based on the percentage set (**FROM 0% UP TO 100% FASTER**); all safety devices will be excluded

● Wire the button to be used as an emergency closing command, the the «PARTIAL START» input

● The E.F.O. function can be enabled by setting the speed increase percentage during the emergency closing on menu 136




15 - DISPLAY and PROGRAMMING




**CONNECT ALL THE ACCESSORIES WHEN THE CONTROL UNIT IS SWITCHED OFF!
AFTER ALL CONNECTIONS HAVE BEEN MADE, POWER ON THE UNIT FOR SETTINGS**

15.1 - POWER ON THE CONTROL UNIT



15.2 - BASIC MENU and SPECIAL MENU

- The control unit has a **BASIC MENU (chapter 16)** which allows the basic settings in order to start using the product quickly
- The **SPECIAL MENU** allows to change default settings, or to enable/disable the accessories or the control unit functions
- To access the **SPECIAL MENU** use one of the two following methods:



➔ In the **BASIC MENU** it is possible to **select the operator type** in use and other necessary options. Once the type has been chosen, all the special menus are automatically set to the default values useful for that operator, so further settings may not be necessary.

15.3 - QUICK START - SEE CHAPTER 18!

- Make all connections (**control unit OFF!**): motors, accessories and power cables
 - **DO NOT jumper the N.C. contacts! - automatic detection of the N.C. contacts not in use!**
 - Power on the control unit and check the correct status of the inputs (**chapter 17**)
 - Enter the basic menu and set the following menus:
(if you do not set a time on menu 7, the logic will be «**semi-automatic**» - automatic reclosing disabled)
- 1
LANGUAGE

3
MOTOR

4
GATES
NUMBER



6
LOGIC

7
TIMER
TO CLOSE
- Move the operator using the menus


192
MOVE
GATE 1

 or

193
MOVE
GATE 2

 ; if the gate opens by pressing  and if the gate closes by pressing , the motors run correctly, otherwise swap the motors cables
 - If installed, check the activation of the correct type of encoder or potentiometer, by accessing the special menu 32 - paragraph 18.2
 - Start up the working times learning by following the procedure in **chapter 18**
- 32
ENCODER

16 - BASIC MENU



17 - INPUTS STATUS MANAGEMENT


- Every input corresponds to a fixed position on the display, according to the diagram below
- Every input can be: **NORMALLY OPEN (0)** - **NORMALLY CLOSED (1)**

0

N.O. - NORMALLY OPEN

1

N.C. - NORMALLY CLOSED




1	START (*)	9	MOTOR 1 OPENING LIMIT SWITCH
2	PARTIAL START	10	MOTOR 1 CLOSING LIMIT SWITCH
3	STOP	11	MOTOR 2 OPENING LIMIT SWITCH
4	PHOTOCELL 1	12	MOTOR 2 CLOSING LIMIT SWITCH
5	PHOTOCELL 2	13	E1/D1 (DATA M1) (**)
6	SAFETY EDGE 1	14	E2/D2 (DATA M2) (**)
7	SAFETY EDGE 2	15	GP1 (**)
8	NOT IN USE	16	GP2 (**)



* If a **TIMER** is connected to the **START** input, it keeps the contact normally closed; in this case the display will show «T» on position n° 1

** Inputs available only if the slowdown limit switches are wired or with «2PM» model - chapter 5

- Example: if you give a «**START**» command, its input switches from normally open to normally closed



- Example: if you pass by the photocell, its input switches from normally closed to normally open



17.1 - ACCESS TO THE INPUTS MANAGEMENT MENU

GO ON ANY
BASIC MENU NUMBER

1
LANGUAGE

HOLD PRESSED
5 SECONDS

INPUTS MANAGEMENT
MENU

START
OFF

- The «inputs management menu» shows the inputs in their current status: ON or OFF

(EXAMPLE)


START
OFF

(EXAMPLE)


STOP
ON

- Inside the «**INPUTS MANAGEMENT MENU**» it is possible to enable or disable the inputs; **paragraph 17.2**

- START** and **PARTIAL START** are **NORMALLY OPEN (N.O.)** contacts
If «**ON**» is displayed when the contact is activated, then the input works
If «**OFF**» is displayed when the contact is activated, then check the wirings




- ALL OTHER CONTACTS** are **NORMALLY CLOSED (N.C.)** contacts
If «**OFF**» is displayed when an accessory is wired, then the input works
If «**ON**» is displayed when an accessory is wired, then check the wirings



➡ **THE LIMIT SWITCHES INPUTS CANNOT BE MANAGED, BUT ONLY DISPLAYED IN THEIR CURRENT STATE (ON OR OFF)**

17.2 - INPUTS MANAGEMENT MENU

THIS MENU ALLOWS TO ENABLE OR DISABLE THE INPUTS WITHOUT REPEATING THE WORKING TIMES LEARNING



LIMIT SWITCHES INPUTS ARE ONLY DISPLAYED.
THEY CAN NOT BE MANAGED!

THE SLOWDOWN LIMIT SWITCHES INPUTS
ARE SHOWN ONLY IF CONNECTED

* IT DISPLAYS THE VOLTAGE
LEVEL OF THE BATTERIES

18 - WORKING TIMES LEARNING




DANGER!

HAVE A QUALIFIED SERVICE PERSON TO CARRY OUT THE OPERATIONS IN SAFE CONDITIONS

- ➡ Check the correct operation of all accessories (photocells, buttons, etc.)
- ➡ Do not jumper the inputs not in use (limit switch, safety edge, etc.)


18.1 - PRELIMINARY SETTINGS

➡ **Before programming the working times, it is necessary to carry out the essential settings of the basic menu. It is not possible to correctly start-up the times learning without carrying-on the following settings!**




18.2 - ENCODER OR POTENTIOMETER ACTIVATION (IF INSTALLED)

● If the operator is equipped with an encoder or potentiometer (POSITION GATE), then it is necessary to check that they are correctly enabled in special menu 32, **before the working times learning!**




18.3 - QUICK LEARNING - ONLY FOR SEA SLIDING OPERATORS

- The control unit on board the SEA sliding operators is pre-set by default (model and parameters) to allow the quick learning of the working times



18.4 - WORKING TIMES LEARNING BY LIMIT SWITCH

- Working times learning through automatic detection of the limit switches
- Check that the special menu 32 is «OFF» (see paragraph 18.2)
- Check on the **INPUTS STATUS MENU** (chapter 17) that the correct limit switch is engaged for each movement direction
- Start-up the working times learning by following the procedure below:




- If the motor starts closing, reaches the limit switch lever and stops, then swap the limit switch cables and repeat the procedure;

- If the motor starts opening, reaches the limit switch lever and stops, then swap the motor cables and repeat the procedure;


18.5 - WORKING TIMES LEARNING BY STANDARD/«ABC»/«NATIVE» ENCODER

- Working times learning through automatic detection of the end-of-stroke points
- Check that the correct encoder type is enabled in special menu 32 (see paragraph 18.2)
- Start-up the working times learning by following the procedure below



➡ With a single motor or barrier, always starting with leaf (or beam) at halfway, the learning cycle will be: **CLOSE - OPEN - CLOSE**;

➡ If the operators perform the first learning cycle starting in opening, wait for the end of the cycle and reverse the motors rotation through the menu 5, then repeat the learning procedure



- After the learning, it is possible to verify the correct reading of the impulses by accessing the following menus (paragraph 4.1)

47	48	49	50
ENCODER PAR M1	ENCODER TOT M1	ENCODER PAR M2	ENCODER TOT M2

- After the learning, it is possible to adjust the sensitivity parameters by the following menus (paragraph 4.2)

33	34	35	36
M1 OPENING SENSITIVITY	M1 CLOSING SENSITIVITY	M2 OPENING SENSITIVITY	M2 CLOSING SENSITIVITY


18.6 - WORKING TIMES LEARNING BY POTENTIOMETER or «RT» ENCODER

FOR «RT» ENCODER: USE THIS PROCEDURE ONLY ON SWING GATE OPERATORS!

- Working times learning through the automatic detection of the end-of-stroke points
- Enable the «**POSITION GATE**» or «**RT**» **ENCODER** in special menu 32 (see paragraph 18.2)
- Start-up the working times learning by following the procedure above (see paragraph 18.5)

➡ At the end of the learning procedure, the gate carries out the following cycle:
M2 CLOSES - M1 CLOSES - M1 OPENS - M2 OPENS - M2 CLOSES - M1 CLOSES - M1 OPENS WITH SLOWDOWN - M2 OPENS WITH SLOWDOWN - M2 CLOSES WITH SLOWDOWN - M1 CLOSES WITH SLOWDOWN

➡ If the operators perform the first learning cycle starting in opening, wait for the end of the cycle and reverse the motors rotation through the menu 5, then repeat the learning procedure



! In case the «**POTENTIOMETER DIRECTION**» alarm is displayed, swap the brown wire with the blue wire and repeat the times learning - **VALID ONLY FOR LINEAR POTENTIOMETER!**

- After the learning, it is possible to check the correct reading of the impulses by accessing the following menus (paragraph 4.4):

51	52	53	54	55	56
I. PAR. M1	I. AP. M1	I. CH. M1	I. PAR. M2	I. AP. M2	I. CH. M2

- After the learning, it is possible to adjust the sensitivity parameters by the following menus (paragraph 4.5):


33	34	35	36	37
M1 OPENING SENSITIVITY	M1 CLOSING SENSITIVITY	M2 OPENING SENSITIVITY	M2 CLOSING SENSITIVITY	SLOW DOWN SENSITIVITY



18.7 - MANUAL WORKING TIMES LEARNING - *Sliding operators with «RT» encoder*

Use this procedure only on operators for SLIDING gates equipped with «RT» ENCODER!

- Check that the correct operator type has been set on menu 3 (see paragraph 18.1)
- Check that the «RT» ENCODER is enabled in special menu 32 (see paragraph 18.2)
- Start up the working times learning by following the procedure below:



➔ At the end of the learning procedure, the gate carries out the following cycle: **CLOSE - OPEN - CLOSE - OPEN WITH SLOWDOWN - CLOSE WITH SLOWDOWN**

➔ At the end of the learning procedure, it is possible to fine-tune the end-of-stroke points by 1 cm pitch through the menus 52 or 53:


52
I. AP. M1

53
I. CH. M1


18.8 - MANUAL WORKING TIMES LEARNING WITH «RS 485» ENCODER

Use this procedure only on «JOINT» or «BIG FAST» operators with «RS 485» ENCODER

- Check that the correct operator type has been set on menu 3 (see paragraph 18.1)
- Check that the «RT» ENCODER is enabled in special menu 32 (see paragraph 18.2)
- Follow the **procedure in the previous paragraph (18.7)** up to the programming in menu 9, then continue by following the steps below:




18.9 - WORKING TIMES LEARNING BY MANUAL PULSES


FOR OPERATORS WITHOUT LIMIT SWITCH, WITHOUT ENCODER AND WITHOUT POTENTIOMETER (I.E: DOUBLE SWING GATE OPERATORS)

- Times learning through manual pulses on the points of stop
- Check that the menu 32 is «OFF» (see paragraph 18.2); if necessary, manually adjust the working times by the menus: (these menus are available only when the menu 32 is «OFF»)

65 M1 OPENING TIME	66 M1 CLOSING TIME	67 M2 OPENING TIME	68 M2 CLOSING TIME
--------------------------	--------------------------	--------------------------	--------------------------




➔ If the operators perform the first learning cycle starting in opening, wait for the end of the cycle and reverse the motors rotation through the menu 5, then repeat the learning procedure




18.10 - LEARNING BY MANUAL PULSES - with POTENTIOMETER or «RT» ENCODER

- Times learning through POTENTIOMETER or «RT» ENCODER which detect the manual pulses on the desired points of stop (allowing the choice of the end-of-stroke points)
- Enable the POTENTIOMETER OR «RT» ENCODER on menu 32 (paragraph 18.2)



➔ If the operators perform the first learning cycle starting in opening, wait for the end of the cycle and reverse the motors rotation through the menu 5, then repeat the learning procedure



! In case the «POTENTIOMETER DIRECTION» alarm is displayed, swap the brown wire with the blue wire and repeat the times learning - VALID ONLY FOR LINEAR POTENTIOMETER!

- After the learning, it is possible to check the correct reading of the impulses by accessing the following menus (paragraph 4.4):

51 I. PAR. M1	52 I. AP. M1	53 I. CH. M1	54 I. PAR. M2	55 I. AP. M2	56 I. CH. M2
------------------	-----------------	-----------------	------------------	-----------------	-----------------



- After the learning, it is possible to adjust the sensitivity parameters by the following menus (paragraph 4.5):


33 M1 OPENING SENSITIVITY	34 M1 CLOSING SENSITIVITY	35 M2 OPENING SENSITIVITY	36 M2 CLOSING SENSITIVITY	37 SLOW DOWN SENSITIVITY
---------------------------------	---------------------------------	---------------------------------	---------------------------------	--------------------------------







19 - LOGICS



THE DEFAULT LOGIC IS «AUTOMATIC», ANYWAY IT CAN BE CHANGED AFTER THE WORKING TIMES LEARNING!


- SEMI-AUTOMATIC LOGIC:** automatically set when the menu 7 is «OFF» (*automatic reclosing disabled*)
 
- SEMI-AUTOMATIC operation:** a **START** command opens the gate; another **START** command closes; *In semi-automatic logic, the automatic reclosing is always disabled.*
- This logic matches with other logics (*except «AUTOMATIC»*), keeping the automatic reclosing disabled
- AUTOMATIC LOGIC:** pre-set by default. Anyway it can be manually enabled through the menu 6 or through the menu 7 by setting a pause time different than 0 and up to 240 seconds (*The menu 7 also enables the automatic reclosing when different than 0*)
 

 (EXAMPLE)
 


- Through the menu 8 it is possible to choose if the **START** command given during the pause time is accepted or not
- AUTOMATIC operation:** a **START** command opens the gate; another **START** command is not accepted if given during the opening; a **START** command reverses the movement if given during the closing
- SAFETY LOGIC:** a **START** command opens the gate; another **START** command reverses the movement if given during the opening a **START** command reverses the movement if given during the closing
 
- STEP BY STEP TYPE 1 LOGIC:** the **START** command follows the logic: **OPEN - STOP - CLOSE - STOP - OPEN**

- STEP BY STEP TYPE 2 LOGIC:** the **START** command follows the logic: **OPEN - STOP - CLOSE - OPEN**

- DEAD MAN LOGIC:** the gate opens as long as the **START** command is held pressed; when released the gate stops. The gate closes as long as the **PARTIAL START** is held pressed; when released the gate stops.
 
- 2 BUTTONS LOGIC:** a **START** command opens the gate; a **PARTIAL START** command closes the gate
 The **START** command reopens the gate if given during the closing. The **PARTIAL START** command is not accepted if given during the opening or during the closing
 

20 - PASSWORD


- Once the password is enabled, all the menus can not be adjusted, they are only displayed
- If you forget the password, contact the SEA technical assistance: **SEA reserves the right to evaluate and decide whether to provide or not the unlocking procedure**




21 - RECEIVERS AND TRANSMITTERS

 **CONNECT THE RECEIVER CIRCUIT WHEN THE CONTROL UNIT IS NOT POWERED, AS INDICATED IN CHAPTER 13**


- **When the control unit is switched-off**, check if the receiver is correctly plugged in
- Program the transmitters before connecting the antenna
- Program the transmitters only when the gate is closed and the motor is stopped
- **RF UNI** and **RF UNI PG** allow the use of both **ROLL PLUS/UNI TX** and **FIX CODE TX**
- **RF FIX** allows the use of the **FIX CODE** transmitters only
- It is possible to store up to 2 among the available functions
- The **START** command must **ALWAYS** be stored on the first channel of the TX
- If the second stored function is modified, then all the transmitters acquire this change on the second channel

 **THE FIRST STORED TRANSMITTER DETERMINES THE CODING OF THE FOLLOWING ONES**
if the first transmitter is stored as *ROLLING CODE*, then all the followings must be stored as *ROLLING CODE*;
transmitters with different coding are not accepted - see the coding passage on Tx instruction!


21.1 - OLD «ROLLING CODE» CODING




21.2 - «ROLLING CODE PLUS» - «UNI» - «FIX CODE» TRANSMITTERS



21.3 - «START» COMMAND QUICK LEARNING




21.4 - TRANSMITTERS FUNCTIONS DIAGRAM



22 - ALARMS

22.1 - FAULTS SHOWN ON THE DISPLAY

- The control unit advises of the faults may happen through a message on the display (*Note: press ok to exit the message*)
- Below the list of the faults that are signaled on the display and the possible solutions to the problems (*if the fault message holds out, contact the technical support*)



WARNING MESSAGE	SOLUTION
NETWORK FAULT	CHECK THE PRESENCE OF THE POWER SUPPLY; CHECK THE FUSE F2
FAULT 24	CHECK FOR ANY OVERLOADS OR SHORT CIRCUITS ON THE WIRING OR ON THE CONTROL UNIT
FAULT COMIS	CHECK THE OPERATION OF COMIS CONTACT AND THE ACCESSORIES WIRING ON THE CONTROL UNIT
SAFETY EDGE 1 FAULT	CHECK THE METAL WIRE AND THE CONNECTION CABLES; MAKE SURE THE CONTACT IS CLOSED
SAFETY EDGE 2 FAULT	CHECK THE METAL WIRE AND THE CONNECTION CABLES; MAKE SURE THE CONTACT IS CLOSED
PHOTO 1 FAULT	CHECK THE OPERATION OF THE PHOTOCELLS OR THEIR WIRINGS ON THE CONTROL UNIT
PHOTO 2 FAULT	CHECK THE OPERATION OF THE PHOTOCELLS OR THEIR WIRINGS ON THE CONTROL UNIT
LIMIT SWITCH FAULT	CHECK THE INTEGRITY OF THE LIMIT SWITCH LEVER
POTENTIOMETER 1 FAULT	THE MESSAGE APPEARS ONLY IF THE POTENTIOMETER IS ON; CHECK THE WIRINGS
POTENTIOMETER 2 FAULT	THE MESSAGE APPEARS ONLY IF THE POTENTIOMETER IS ON; CHECK THE WIRINGS
POTENTIOMETER 1 DIRECTION FAULT	SWAP THE CONNECTION CABLES OF THE POTENTIOMETER (SWAP THE BLUE CABLE WITH THE BROWN)
POTENTIOMETER 2 DIRECTION FAULT	SWAP THE CONNECTION CABLES OF THE POTENTIOMETER (SWAP THE BLUE CABLE WITH THE BROWN)
SERIAL INVERTER 1 FAULT	LOGIC MICROPROCESSOR IRREVERSIBLY DAMAGED. REPLACE THE CONTROL UNIT
SERIAL INVERTER 2 FAULT	LOGIC MICROPROCESSOR IRREVERSIBLY DAMAGED. REPLACE THE CONTROL UNIT
SERIAL INVERTER FAULT FROM MODULE 1	«FV» INVERTER MODULE 1 IRREVERSIBLY DAMAGED. REPLACE THE CONTROL UNIT
SERIAL INVERTER FAULT FROM MODULE 2	«FV» INVERTER MODULE 2 IRREVERSIBLY DAMAGED. REPLACE THE CONTROL UNIT
INVERTER 1 FAULT (followed by ERROR CODE)	«FV» INVERTER MODULE 1 FAULT - CHECK THE ERROR CODE TABLES BELOW
INVERTER 2 FAULT (followed by ERROR CODE)	«FV» INVERTER MODULE 2 FAULT - CHECK THE ERROR CODE TABLES BELOW
PASSWORD ERROR	PASSWORD ERROR - CONTACT THE TECHNICAL ASSISTANCE
POTENTIOMETER 1 FAULT - MECHANICAL	ROTARY ENCODER 1 - RS 485 FAULT - REPLACE THE ENCODER
POTENTIOMETER 2 FAULT - MECHANICAL	ROTARY ENCODER 2 - RS 485 FAULT - REPLACE THE ENCODER
POTENTIOMETER 1 FAULT - VOLTAGE	NO POWER SUPPLY OR WRONG VOLTAGE ON ROTARY ENCODER 1 - RS 485
POTENTIOMETER 2 FAULT - VOLTAGE	NO POWER SUPPLY OR WRONG VOLTAGE ON ROTARY ENCODER 2 - RS 485
FAULT 1 - RS 485	NO COMMUNICATION BETWEEN ROTARY ENCODER 1 - RS 485 AND RS 485 UNIT
FAULT 2 - RS 485	NO COMMUNICATION BETWEEN ROTARY ENCODER 2 - RS 485 AND RS 485 UNIT
RS 485 - SERIAL FAULT	NO COMMUNICATION BETWEEN RS 485 UNIT AND UNIGATE

22.2 - NUMERICAL ERROR CODES

- Some «INVERTER» fault warnings are followed by a numerical error code which specifies the type of problem on the «FV» module
- Sometimes it may happen that more than one problem is detected at the same time, therefore the numerical code of one error is added to the numerical code of the other; below also the error sums table

NUMERICAL CODE	DESCRIPTION
2	MAXIMUM VOLTAGE EXCEEDED
4	MINIMUM VOLTAGE EXCEEDED
8	MAXIMUM TEMPERATURE EXCEEDED ON «FV»
16	MAXIMUM TEMPERATURE EXCEEDED ON «FV»
64	MAXIMUM CURRENT EXCEEDED ON «FV»
256	«FV» MODULE COMMUNICATION ERROR
512	FORCED SHUTDOWN OF THE «FV» MODULE FOR PROTECTION AGAINST POSSIBLE FAILURE

ERRORS SUMS TABLE							
	2	4	8	16	64	256	512
2	—	6	10	18	66	258	514
4	—	—	12	20	68	260	516
8	—	—	—	24	72	264	520
16	—	—	—	—	80	272	528
64	—	—	—	—	—	320	576
256	—	—	—	—	—	—	768
512	—	—	—	—	—	—	—

➔ **Example: if both error n° 8 and error n° 256 are detected, the display will show only the number 264 which is the sum of 8 + 256, as you can see in the table**

22.3 - FAULTS SIGNALLED ON THE FLASHING LIGHT


- It is also possible to visualize the warning signals through the flashing light simply by observing the number of flashes emitted (*see the table of correspondences below*)
- When an event occurs, the warning flashes will be issued at each «START» command

ALARM TYPE	NUMBER OF FLASHES	NOTES
COMIS	8 FAST (EVERY 0.2 SEC) FOR 9 TIMES	COMIS FAULT - CHECK WIRINGS
INVERTER 1 FAULT	10 SLOW (EVERY 0.5 SEC) FOR 6 TIMES	REPAIR OR REPLACEMENT NEEDED
INVERTER 2 FAULT	12 SLOW (EVERY 0.5 SEC) FOR 6 TIMES	REPAIR OR REPLACEMENT NEEDED
REPORT PHOTO 1 - 2 IN CLOSING	2 SLOW (EVERY 0.5 SEC) FOR 5 TIMES	CLOSING PHOTOCELL FAULT
REPORT PHOTO 1 - 2 IN OPENING	3 SLOW (EVERY 0.5 SEC) FOR 1 TIME	OPENING PHOTOCELL FAULT
REPORT COLLISION IN OPENING	6 SLOW (EVERY 0.5 SEC) FOR 11 TIMES	OBSTACLE DETECTED IN OPENING
REPORT COLLISION IN CLOSING	6 SLOW (EVERY 0.5 SEC) FOR 11 TIMES	OBSTACLE DETECTED IN CLOSING
REPORT SAFETY EDGE	4 SLOW (EVERY 0.5 SEC) FOR 4 TIMES	SAFETY EDGE FAULT
SAFETY EDGE 1 - 2 FAULT	4 SLOW (EVERY 0.5 SEC) FOR 4 TIMES	SAFETY EDGE FAULT
PHOTO 1 FAULT	3 SLOW (EVERY 0.5 SEC) FOR 1 TIME	PHOTOCELL 1 FAULT
PHOTO 2 FAULT	3 SLOW (EVERY 0.5 SEC) FOR 1 TIME	PHOTOCELL 2 FAULT
POTENTIOMETER 1 FAULT	11 FAST (EVERY 0.2 SEC) FOR 4 TIMES	ABSOLUTE POTENTIOMETER 1 FAULT
POTENTIOMETER 2 FAULT	11 FAST (EVERY 0.2 SEC) FOR 4 TIMES	ABSOLUTE POTENTIOMETER 2 FAULT
STOP	5 SLOW (EVERY 0.5 SEC) FOR 2 TIMES	STOP CONTACT FAULT
LIMIT SWITCH FAULT	4 FAST (EVERY 0.2 SEC) FOR 11 TIMES	LIMIT SWITCH FAULT
CYCLES ALARM	7 SLOW (EVERY 0.5 SEC) FOR 2 TIMES	MAXIMUM CYCLES ACHIEVED - MAINTENANCE
ROTARY ENCODER 1 FAULT - RS 485	5 SLOW (EVERY 0.5 SEC) FOR 6 TIMES	ROTARY ENCODER 1 - RS 485 FAULT
ROTARY ENCODER 2 FAULT - RS 485	5 FAST (EVERY 0.2 SEC) FOR 6 TIMES	ROTARY ENCODER 2 - RS 485 FAULT

➡ The «CYCLES ALARM» warning refers to the reaching of the maximum cycles number established after which the maintenance is necessary

22.4 - «DIAGNOSTICS» MENU TO DISPLAY LATEST EVENTS

- The warnings and the alarms remain in the control unit memory, up to a max. of 10 events. To see the stored events, access the menu 106. Below is the table with the type of events saved in the diagnostics



➡ If the fault message holds out, carry out the required checks or disconnect the device generating the fault

TYPE OF EVENT	WARNING MESSAGE STORED
EVENTS OR ALARMS REGARDING FAULTS ON PHOTOCELL 1 OR PHOTOCELL 2 IN OPENING	PHOTO OPENING
EVENTS OR ALARMS REGARDING FAULTS ON PHOTOCELL 1 OR PHOTOCELL 2 IN CLOSING	PHOTO CLOSING
EVENTS OR ALARMS REGARDING THE DETECTION OF OBSTACLES IN THE OPENING PHASE	OBSTACLE IN OPENING
EVENTS OR ALARMS CONCERNING THE DETECTION OF OBSTACLES IN THE CLOSING PHASE	OBSTACLE IN CLOSING
EVENTS OR ALARMS CONCERNING FAULTS ON THE SAFETY EDGE 1	SAFETY EDGE 1 FAULT
EVENTS OR ALARMS CONCERNING FAULTS ON THE SAFETY EDGE 2	SAFETY EDGE 2 FAULT
EVENTS OR ALARMS CONCERNING FAULTS ON THE ABSOLUTE POTENTIOMETER 1 OR 2	POT.1 / POT.2 FAULT
EVENTS OR ALARMS REGARDING FAULTS ON THE STOP CONTACT	STOP
REACHING OF THE MAXIMUM CYCLES ESTABLISHED - MAINTENANCE REQUIRED	MAINTENANCE
EVENTS OR ALARMS CONCERNING FAULTS ON THE MAIN POWER SUPPLY	MISSING NETWORK
EVENTS OR ALARMS CONCERNING FAULTS ON THE OPENING OR CLOSING LIMIT SWITCHES	LIMIT SWITCH
EVENTS OR ALARMS CONCERNING THE EMERGENCY MANŒUVRES PERFORMED	CLOSE ALWAYS
EVENTS OR ALARMS CONCERNING THE EMERGENCY MANŒUVRES PERFORMED	EMERGENCY
EVENTS OR ALARMS REGARDING FAULTS ON THE FIRST «FV» INVERTER MODULE	INVERTER 1
EVENTS OR ALARMS REGARDING FAULTS ON THE SECOND «FV» INVERTER MODULE	INVERTER 2
EVENTS OR ALARMS REGARDING FAULTS ON THE FIRST «FV» INVERTER MODULE	INVERTER MODULE 1
EVENTS OR ALARMS REGARDING FAULTS ON THE SECOND «FV» INVERTER MODULE	INVERTER MODULE 2
EVENTS OR ALARMS REGARDING FAULTS ON ACCESSORIES CONNECTED TO THE «COMIS» INPUT	COMIS



IT IS ALWAYS RECOMMENDED TO CONSULT THE CHAPTER 23 DEDICATED TO TROUBLESHOOTING. MOST OF THE PROBLEMS CAN BE SOLVED BY FOLLOWING THE GIVEN INSTRUCTIONS!

23 - TROUBLESHOOTING



MAKE SURE THAT ALL THE SAFETY DEVICES ARE «ON»

PROBLEM	POSSIBLE REASON	SOLUTION
The operator does not respond to any START command	a) Check that the N.C. are connected b) Blown fuse	a) Check the connections and the jumpers on the safety edge or stop or photocell inputs, if connected b) Replace the blown fuse on the control unit
The operator does not run and the diagnostic display is off	a) The control unit is not powered b) Fuse open c) Defective control unit	a) Check the AC power supply b) Check the fuses c) Replace the defective control unit
The operator does not respond to a wired command (example: Opening, Closing, etc.)	a) Check the inputs of the opening and closing commands b) The STOP button is activated c) The Reset button is blocked d) Anti-entrapment safety device active	a) Check all the opening and closing inputs to make sure they are not blocked b) Check the STOP button is not blocked c) Check the Reset button d) Check among all the inputs of the anti-entrapment protection device, if there is a blocked sensor
The operator does not respond to a remote control	a) The STOP button is activated b) The Reset button is blocked c) Poor radio reception	a) Check the STOP button is not blocked b) Check the Reset button c) Check if the other wired devices are working correctly; check the antenna cable
The motor runs in one direction only	a) Check that the resistance value between the phase and neutral of the motor is MOhm b) Try to reverse the phase of the motor and see if it changes direction or not	a) Replace the cable b) If the motor is blocked, replace the cable; if the motor moves in only one direction, the motor direction relay is damaged
The gate does not move but the motor runs	a) The engine is in the locked position b) Presence of an obstacle	a) Release the motor b) Remove the obstacle
The gate does not reach the complete open or closed position	a) Wrong limit switch setting b) Programming error c) Gate is stopped by an obstacle d) Torque too low e) The gate is too heavy to perform the automatic slowdown	a) Set the limit switches b) Repeat the working times programming c) Remove the obstacle d) Increase the torque parameter e) Set the slowdown to OFF
The gate opens but does not close	a) The photocells contacts are connected and open b) Stop contact connected and open c) The safety edge contact is open d) Amperometric alarm	a) b) c) Check the jumpers or the connected devices or the warning signals on the flashing lamp d) Check for a possible the amperometric alarm and, if necessary, increase the torque parameter
The gate does not close automatically	a) Pause time set too high b) Semi-automatic logic control unit	a) Adjust the pause time b) Set the PAUSE TIME menu to a value different than OFF
The gate moves, but the limit switches cannot be set correctly	a) The gate does not move towards a stop position b) It is too difficult to move the gate	a) Manually unlock and move the gate and make sure the gate moves easily from limit switch to limit switch. If necessary, repair the gate b) The gate must be able to move easily and freely throughout its travel, from limit switch to limit switch. If necessary, repair the gate
The gate does not fully open or close when the limit switches are set	a) The gate does not move towards a limit switch b) It is too difficult to move the gate	a) Manually unlock and move the gate and make sure the gate moves easily from limit switch to limit switch. If necessary, repair the gate b) The gate must be able to move easily and freely throughout its travel, from limit switch to limit switch. If necessary, repair the gate
The gate stops during travel and reverses direction	a) Open/Close control active b) The obstacle detection sensitivity is too low	a) Check if there is an active input among all the opening and closing inputs b) Check the obstacle detection sensitivity value and try to increase it
The gate does not respect the slowdown start points	a) The encoder does not work properly when activated b) Slow mechanical clutch c) Too large deceleration space d) The potentiometer does not work correctly when activated e) The parameters of the recovery position are too high or too low	a) Check in the Encoder menu that the "Encoder Par" parameter is set from a low value of +/- 10 (gate completely closed) to "Encoder tot" (gate completely open). If the IPAR movement is not in line with the range of values (from +/- 10 to "Encoder tot") probably the encoder is defective b) Tighten the mechanical clutch c) Reduce the slowdown space d) Check in the Potentiometer menu that the "IPAR" parameter is set from "I.CH." (gate completely closed) to "I.AP." (gate completely open). If the "IPAR" movement is not in line with the range of values (from I.AP. to I.CH.), the potentiometer is probably faulty e) Reduce or increase the values of the "recovery position"

PROBLEM	POSSIBLE REASON	SOLUTION
The gate opens but does not close with TX or closing timer	a) Opening control active b) Pause not set c) The closing anti-entrapment protection device is active d) The photocell contact is open e) The fire switch input is active	a) Check if there is an active input among the open inputs b) Check the pause settings c) Check if there is an active sensor among all the inputs of the anti-entrapment protection device d) Check the contact of the photocells e) Check the fire switch input
The gate opens suddenly but any START command have been given	a) Frequency or disturbances on the main line b) Short-circuit on the START contact	a) The AC wiring must be separated from the DC wires and run through separate conduits. If it is a frequency disturbance, you can change the frequency to another MHz value, such as 868 or FM b) Check all the START contacts
The gate does not accept the close command during the pause in automatic logic, even if the loop or photocell are set as Start	a) START IN PAUSE is not ON b) The photocell/loop input is not set as "pause reload"	a) Turn ON the START IN PAUSE menu b) Set "pause reload" in the photocell / loop menu
The gate does not have the necessary force to close or reach the limit switch	a) Slowing down is not possible either because the gate is too heavy or because of the inclination or because the installation is not new	a) Set the slowdown to OFF
The gate travel is obstructed and cannot stop or reverse	a) Force the necessary adjustment	a) Refer to the adjustment parameter to carry out the obstruction tests and make the correct adjustments of the force (sensitivity - torque)
The photocell does not stop or reverse the gate travel	a) The photocell wiring is incorrect b) The photocell is faulty c) The photocells have been installed too far apart	a) Check the photocell wiring. Check that the gate stops and reverses its direction when the photocell is engaged b) Replace the faulty photocell. Check that the gate stops and reverses its direction when the photocell is engaged c) Install the photocells closer or use safety edges with sensors
The safety edge does not stop or reverse the travel of the gate	a) Incorrect wiring of the edge sensor b) Defective edge sensor	a) Check the safety edge wiring. Check that the gate stops and reverses its direction when the edge is activated b) Replace the defective safety edge and check that the gate stops and reverses its direction when it is activated
The alarm sounds for 5 minutes or the alarm sounds after a command	a) A double entrapment has occurred (two obstructions within a single activation)	a) Check the cause of the entrapment detection (obstruction) and correct it. Press the reset button to silence the alarm and reset the operator
The shadow loop does not hold the gate on the opening limit switch	a) Shadow loop sensor incorrectly adjusted b) Defective shadow loop sensor c) Wrong setting	a) Check the shadow loop settings and reset as needed b) Replace the defective vehicle sensor c) Check that menu 98 is on SHADOW LOOP
The accessories connected to the 24V accessory power supply do not work properly, they turn off or restart	a) Accessory power supply protection active b) Defective electronic control unit	a) Disconnect all devices powered by the 24V output for the accessories power supply and measure their voltage (must be 23-30 Vdc). If the voltage is correct, reconnect the accessories one at a time, measuring each time the voltage b) Replace the defective control unit
Fault on the 24VAUX	a) Overload/short-circuit on AUX input b) Blown fuse	a) Check if the cable is shorted b) Replace the fuse
The control unit turns on but the motor does not run	a) STOP active or wrong jumpers b) Open or close the active input c) Active Entrapment Protection Device d) Defective electronic control unit	a) Check that the STOP button is not blocked, that it is a N.C. contact or put a jumper on the Stop input b) Check that none of the opening and closing inputs are blocked c) Check whether there is a blocked sensor among all the entrapment protection device inputs d) Replace the defective control unit

UNIGATE - MENU FUNCTIONS TABLE

LEGEND

INVERTER - FUNCTION AVAILABLE ON MODEL UNIGATE WITH «FV» INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)

2PM - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE

24V - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 24V MODULE

BR - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 36V BRUSHLESS MODULE



ALL - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
1	LANGUAGE	Italiano	Italian	ALL	English	
		English	English			
		Français	French			
		Español	Spanish			
		Dutch	Dutch			
2	TRANSMITTERS	START	START	ALL	START Partial opening	
		Partial START	Partial START			
		External module	External module	INVERTER 24V - 2PM		
		STOP	STOP	ALL		
		Relay 1	To enable the Relay 1 for 3 seconds To store the Relay activation command on the Tx, first set the menu 132-RELAY 1 to «RelayTX»			
		Relay 2	To enable the Relay 2 for 3 seconds To store the Relay activation command on the Tx, first set the menu 133-RELAY 2 to «RelayTX»			
		Bistable STOP	Pressed once, it stops the gate. Pressed twice, it reactivates the START input			
		Latch opening	One impulse opens and keep open. A second impulse restore the movement			
		Latch closing	One impulse closes and keep closed. A second impulse restore the movement			
		Unlock	To store a command for unlocking the electric brake			
		Delete a transmitter	To delete a single transmitter (TX)			
		Move to EEPROM	To transfer the transmitters stored on the control unit to the external EEPROM (MEM), if connected			
		Clear memory	To delete the full TX memory on the receiver			
		End	To exit the menu «transmitters»			
3	MOTOR	1- Hydraulic	Hydraulic operators - Series I (INVERTER)	INVERTER 2PM	Hydraulic	
		2- Sliding	Sliding operators - Series I (INVERTER)			
		3- Reversible Sliding	Reversible sliding operators - Series I (INVERTER)			
		4- Mechanic swing	Electromechanic swing operators - Series I (INVERTER)			
		5- Three-phase - Bollards	Three-phase operators and Bollards Series I BIG (INVERTER with BIG module)			
		8- BIG Fast BIG Super Fast 4LS	Sliding operators - Series I BIG (INVERTER with BIG module)	INVERTER		
		9- BIG	Sliding operator - Series I BIG (INVERTER with BIG module)			
		10- JOINT	Hydraulic operator with «RT» Encoder - Series I (INVERTER)			
		60- BIG ABSOLUTE	Sliding operator - Series I BIG (INVERTER with BIG module)			
		61- SEAGEAR ABSOLUTE	Sliding operator - Series I BIG (INVERTER with BIG module)			
		62- RAPID DOOR	Electromechanic operator - Series I (INVERTER)			
		64 - LEPUS FAST *	Sliding operator - Series I (INVERTER)			
		67 - LEPUS	Sliding operators - Series I (INVERTER)			
		68 - VELA IND EA **	Barrier with «RT» Encoder - Serie I (INVERTER)			
		69 - SPRINT EA **	Barrier with «RT» Encoder - Serie I (INVERTER)			
		81 - LEPUS FAST ABSOLUTE	Sliding operator - Series I (INVERTER)			
		82- SLIDING ABSOLUTE	Sliding operator - Series I (INVERTER)			

continues...

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
3	MOTOR	32- ORION BOX FAST	24Vdc electromechanic operator	24V	SURF	
		35- SURF	24Vdc electromechanic operator			
		39- HT 270/390 24VDC	24Vdc hydraulic operator			
		43- SURF FAST	24Vdc electromechanic operator			
		65 KITE LS	24Vdc electromechanic operator			
		50- HALF TANK BR	Hydraulic operator - Series BR (BRUSHLESS)	BR	HALF TANK BR	
		51- SURF BR	Electromechanic swing operator - Series BR (BRUSHLESS)			
		52- SATURN BR	Electromechanic operator - Series BR (BRUSHLESS)			
		53- SURF REVERSIBLE	Electromechanic operator - Series BR (BRUSHLESS)			
		54- SPRINT BR (RT)	Hydraulic barrier with «RT» Encoder (already set by default) - Series BR (BRUSHLESS)			
		55 KITE LS BR	Electromechanic swing operator - BR (BRUSHLESS)			
		56- COMPACT BR	Hydraulic operator - Series BR (BRUSHLESS)			
		57- JOINT BR	Hydraulic operator - Series BR (BRUSHLESS)			
		58- LEPUS RACK BR (ABC)	Sliding operator with «ABC» Encoder - BR (BRUSHLESS)			
		66- LEPUS CHAIN BR***	Sliding operator with chain - Series BR (BRUSHLESS)			
* Only for LEPUS FAST 220V. In case of LEPUS FAST 110V, choose the option 2-Sliding						
** When SPRINT or VELA INDUSTRIAL are set, the menu 32 automatically sets to «RT»; In case of barriers without encoder or different encoder, change the menu 32 settings!						
*** With LEPUS CHAIN BR operator the menu-32 is not shown as set by default on «RT»						
4	GATES NUMBER	From 1 to 2	To set the number of motors to be managed	INVERTER 24V - BR	1	
		From 1 to 4		2PM	2	
5	REVERSE MOTOR	On	To reverse the opening with the closing or vice-versa (both motors and limit-switches are reversed)	ALL	Off	
		Off	Off			
6	LOGIC	Automatic	Automatic	ALL	Auto-matic	
		Open-stop-close-stop-open	Step by step type 1			
		Open-stop-close-open	Step by step type 2			
		2 button	Two buttons			
		Safety	Safety			
		Dead man	Dead man			
7	TIMER TO CLOSE	Off	Semi-automatic logic enabled a START command opens and another START closes the gate - automatic reclosing disabled	ALL	Off	
		1 240	To set a pause time (from 1 second to 4 minutes) before the automatic reclosing			
8	START IN PAUSE	Off	The START command is not accepted during pause	ALL	Off	
		On	The START command is accepted during pause			
9	PROGRAMMING	Off On	To start up the working times learning	ALL	Off	
		Motor Direction	This menu is shown in case of operators with «RS 485» Encoder or in case of a sliding operator with «RT» Encoder - it allows to program one or two operators with RS 485 Encoder, in automatic or manual mode or to program a sliding operator with «RT» Encoder, in manual mode	INVERTER 24V BR		

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
10	TEST START	Off On	To give a START command for testing the operator (This command can be used only if the unit has already been programmed!)	ALL	Off	
11	BEAM LENGTH	3m - 4m - 5m - 6m 7m - 7,5m - 8m	This menu will be shown only if the menu 3-MOTORS is set to the options « 68-VELA IND » or « 69-SPRINT E/A ». It allows to set the beam length (values in meters)	INVERTER BR	----	
	LEAF LENGTH	2m - 3m - 4m - 5m - 6m	This menu will be shown only if the menu 3-MOTORS is set to the option « 10-JOINT ». It allows to set the leaf length (values in meters)			
12	SLOWDOWN LIMIT SWITCH	Off On	This menu will be shown only if the menu 3-MOTORS is set to the options « 5-THREEPHASE-BOLLARDS » or to « HYDRAULIC ». It allows to enable the slowdown limit switches. Only if the operator is equipped with 4 limit switches as standard	INVERTER	Off	
13	LATCH PAUSE	Off On	If «ON» the operator complies with the pause time set when the function «LATCH OPENING» is disabled. When «OFF» the pause time set is not respected	INVERTER 24V BR	Off	
14	RESET	A count-down of 5 seconds will start up by holding the UP button; at its end «INIT» will appear on the display as confirmation of the control board reset				
192	MOVE GATE 1 *	Allows to move the gate in order to test the motor running or simply to position the gate as desired. The command works in a temporary «dead man» mode: HOLD UP PRESSED = THE GATE OPENS HOLD DOWN PRESSED = THE GATE CLOSES		ALL	----	
193	MOVE GATE 2 *	Allows to move the gate in order to test the motor running or simply to position the gate as desired. The command works in a temporary «dead man» mode: HOLD UP PRESSED = THE GATE OPENS HOLD DOWN PRESSED = THE GATE CLOSES		ALL	----	
194	MOVE GATE 3 *	Allows to move the gate in order to test the motor running or simply to position the gate as desired. The command works in a temporary «dead man» mode: HOLD UP PRESSED = THE GATE OPENS HOLD DOWN PRESSED = THE GATE CLOSES		4PM	----	
195	MOVE GATE 4 *	Allows to move the gate in order to test the motor running or simply to position the gate as desired. The command works in a temporary «dead man» mode: HOLD UP PRESSED = THE GATE OPENS HOLD DOWN PRESSED = THE GATE CLOSES		4PM	----	
* The command is accepted only at the end of the cycle or after a STOP; it is not accepted during the cycle and during the pause						
15	END	Press OK to return to the display of the firmware version and to the one of inputs state				
16	SPECIAL MENU	Press OK to enter the special menu				

SPECIAL MENU

PRESS AT THE SAME TIME FOR 5 SECONDS TO ENTER OR TO EXIT THE SPECIAL MENU

LEGEND

INVERTER - FUNCTION AVAILABLE ON MODEL UNIGATE WITH «FV» INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)

2PM - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE



24V - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 24V MODULE

BR - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 36V BRUSHLESS MODULE

ALL - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

SPECIAL MENU		SET		DESCRIPTION	MODEL	DEFAULT	NOTE	
17	OPENING SPEED 1	10%	100%	Motor 1 speed in opening	INVERTER	80%		
		20%	100%		24V			
		30%	100%		BR			
18	CLOSING SPEED 1	10%	100%	Motor 1 speed in closing	INVERTER	80%		
		20%	100%		24V			
		30%	100%		BR			
19	OPENING SPEED 2	10%	100%	Motor 2 speed in opening	INVERTER	80%		
		20%	100%		24V			
		30%	100%		BR			
20	CLOSING SPEED 2	10%	100%	Motor 2 speed in closing	INVERTER	80%		
		20%	100%		24V			
		30%	100%		BR			
21	SLOWDOWN SPEED IN OPENING 1	From 10% to 60% of the maximum speed		Motor 1 slowdown speed in opening	INVERTER 24V - BR	30%		
22	SLOWDOWN SPEED IN CLOSING 1	From 10% to 60% of the maximum speed		Motor 1 slowdown speed in closing	INVERTER 24V - BR	30%		
23	SLOWDOWN SPEED IN OPENING 2	From 10% to 60% of the maximum speed		Motor 2 slowdown speed in opening	INVERTER 24V - BR	30%		
24	SLOWDOWN SPEED IN CLOSING 2	From 10% to 60% of the maximum speed		Motor 2 slowdown speed in closing	INVERTER 24V - BR	30%		
25	LEARNING SPEED	10%	100 %	To adjust the working times learning speed. This parameter can change according to the motor type set on the menu 3	INVERTER	50%		
		20%	100 %		24V BR			
NOTE: The range of values that can be set in all the SPEED menus may vary according to the operator model								
26	LEAF DELAY IN OPENING	Off	6	Total	Adjustable from OFF to 6 seconds or to TOTAL (If set to «Total» the Motor 2 will start opening only after the Motor 1 has completed the movement)	INVERTER 24V BR	1,5	
		Off	6		Adjustable from OFF (disabled) to 6 seconds	2PM		
27	LEAF DELAY IN CLOSING	Off	20	Total	Adjustable from OFF to 20 seconds or to TOTAL (If set to «Total» the Motor 1 will start opening only after the Motor 2 has completed the movement)	INVERTER 24V BR	2,5*	
		Off	20		Adjustable from OFF (disabled) to 20 seconds	2PM		
28	OPENING TORQUE 1	50%	100 %	Motor 1 torque in opening: the higher the torque value, the more force is required to execute the inversion in case of obstacle	INVERTER 2PM	100%		
		10%	100 %		24V			
		5%	100 %		BR			
29	CLOSING TORQUE 1	50%	100 %	Motor 1 torque in closing: the higher the torque value, the more force is required to execute the inversion in case of obstacle	INVERTER 2PM	100%		
		10%	100 %		24V			
		5%	100 %		BR			
30	OPENING TORQUE 2	50%	100 %	Motor 2 torque in opening: the higher the torque value, the more force is required to execute the inversion in case of obstacle	INVERTER 2PM	100%		
		10%	100 %		24V			
		5%	100 %		BR			
31	CLOSING TORQUE 2	50%	100 %	Motor 2 torque in closing: the higher the torque value, the more force is required to execute the inversion in case of obstacle	INVERTER 2PM	100%		
		10%	100 %		24V			
		5%	100 %		BR			
NOTE: The range of values that can be set in all the TORQUE menus may vary according to the operator model								

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
32	ENCODER	ON	ON = Standard Encoder Enabled OFF = Standard Encoder Disabled (when OFF, only the learnt working times are shown)	INVERTER 24V 2PM	It depends on motor	
		Enc ABC	To enable the «ABC» rotary encoder for the position and operation management of the 36V brushless operators	BR	It depends on motor	
		NATIVE	To enable the SURF BR and KITE BR inner Encoder	BR	It depends on motor	
	47 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor1)			
	48 ENCODER TOT. 1	xxx.	Impulses stored during programming (Motor 1)			
	49 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor2)			
	50 ENCODER TOT. 2	xxx.	Impulses stored during programming (Motor 2)			
32	ENCODER	Position Gate	To enable the linear potentiometer «POSITION GATE»	ALL	Off	
		RT	To enable the «RT» absolute encoder	INVERTER BR		
		RS 485	To enable the «RS485» absolute rotary encoder	INVERTER 24V		
	51 I.PAR.M1 *	-----	To show the current position of the potentiometer/absolute encoder on the leaf moved by Motor 1 . This parameter is useful to see if the potentiometer or the absolute encoder are correctly read			
	52 I.AP.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully open			
	53 I.CH.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully close			
	54 I.PAR.M2 *	-----	To show the current position of the potentiometer/absolute encoder on the leaf moved by Motor 2 . This parameter is useful to see if the potentiometer or the absolute encoder are correctly read			
	55 I.AP.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully open			
	56 I.CH.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully close			
* While the partial impulses are displayed, it is possible to OPEN (by pressing UP) or CLOSE (by pressing DOWN) the corresponding operator to verify the correct reading of the potentiometer after installation or simply for checking						
32	ENCODER	OFF	ON = Standard Encoder Enabled OFF = Standard Encoder Disabled (when OFF, only the learnt working times are shown)	ALL	Off	
	65 OPENING TIME M1	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 1). With UP or DOWN it is possible to increase or reduce the working times			
	66 CLOSING TIME M1	xxx.s				
	67 OPENING TIME M2	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 2). With UP or DOWN it is possible to increase or reduce the working times			
	68 CLOSING TIME M2	xxx.s				
33	OPENING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer or «RT» Encoder intervention time on the Motor 1 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
34	CLOSING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer or «RT» Encoder intervention time on the Motor 1 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			
35	OPENING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer or «RT» Encoder intervention time on the Motor 2 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
36	CLOSING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer or «RT» Encoder intervention time on the Motor 2 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
37	SLOWDOWN SENSITIVITY	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer or «RT» Encoder intervention on the Motor during the slowdown	ALL	Off	
		Off (Intervention excluded)	Disabled			
38	M1 POTENTIOMETER THRESHOLD IN OPENING	0 1000 (available only if the «Position Gate» or the «RT» Encoder have been wired and the menu 32 correctly set)	<u>To adjust the threshold of the Potentiometer or «RT» Encoder intervention.</u> This parameter self-determines during the working times learning but can also be adjusted later, on the condition that the set value is lower than the value shown in VP1 or VP2 (<u>instantaneous speed values which can be shown by accessing the DEBUG menu</u>). NOTE: The lower the threshold value, the slower is the response of the potentiometer.	ALL	It depends on motor	
39	M1 POTENTIOMETER THRESHOLD IN CLOSING					
40	M2 POTENTIOMETER THRESHOLD IN OPENING					
41	M2 POTENTIOMETER THRESHOLD IN CLOSING					
42	M1 POTENTIOMETER THRESHOLD IN SLOWDOWN - OPENING	0 100 (available only if the «Position Gate» or the «RT» Encoder have been wired and the menu 32 correctly set)	<u>To adjust the threshold of the Potentiometer or «RT» Encoder intervention during the slowdown.</u> The value can be manually increased on the condition that the set value is lower than the value shown in VP1 or VP2 (<u>instantaneous speed values which can be shown by accessing the DEBUG menu</u>)	ALL	It depends on motor	
43	M1 POTENTIOMETER THRESHOLD IN SLOWDOWN - CLOSING					
44	M2 POTENTIOMETER THRESHOLD IN SLOWDOWN - OPENING					
45	M2 POTENTIOMETER THRESHOLD IN SLOWDOWN - CLOSING					
46	CLOSING INVERSION	Total	In case of obstacle or safety edge intervention during the closing, the gate totally reverses the movement. If the automatic reclosing is enabled (automatic logic), it is attempted for 5 times	ALL	Total	
		Partial	In case of obstacle or safety edge / potentiometer / «RT» Encoder intervention, the gate partially reverses direction (of about 30 cm) then stops			
The menus 47 - 48 - 49 - 50 are shown only if the menu 32- ENCODER = ON						
The menus 51 - 52 - 53 - 54 - 55 - 56 are shown only if the menu 32- ENCODER = Position Gate or RT						
57	WORKING CURRENT 1 Ampere	To display the absorbed current during the Motor 1 operation	INVERTER 24V - BR	----	
58	WORKING CURRENT 2 Ampere	To display the absorbed current during the Motor 2 operation	INVERTER 24V - BR	----	
59	OPENING SLOWDOWN 1	0% 50% (*)	Adjustable from 0% to the 50% of the stroke (0% = slowdown excluded)	ALL	30%	
60	CLOSING SLOWDOWN 1	0% 50% (*)	Adjustable from 0% to the 50% of the stroke (0% = slowdown excluded)	ALL	30%	
61	OPENING SLOWDOWN 2	0% 50% (*)	Adjustable from 0% to the 50% of the stroke (0% = slowdown excluded)	ALL	30%	
62	CLOSING SLOWDOWN 2	0% 50% (*)	Adjustable from 0% to the 50% of the stroke (0% = slowdown excluded)	ALL	30%	
63	DECELERATION	0% 100% 	To adjust the change from normal speed to slowdown speed	ALL	It depends on motor	
64	ACCELERATION	0,1 s 5 s 	Acceleration ramp. To adjust the motor start up speed	ALL	It depends on motor	
* For LEPUS FAST ABSOLUTE operators: 0% = 50 cm 100% = 3 m						
The menus 65 - 66 - 67 - 68 are shown only if the menu 32- ENCODER = OFF or 32- ENCODER = ON						
69	ANTI OVERLAP	Off	To disable the anti-overlapping control of the leaves allowing their separate control	ALL	Off	
		On	To enable the anti-overlapping control of the leaves			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
70	OPENING POSITION RECOVERY	0 20 seconds only if 32-Encoder is OFF	After a STOP or an inversion command given during the opening, the gate recovers the excess space traveled by inertia	ALL	It depends on motor	
71	CLOSING POSITION RECOVERY	0 20 seconds only if 32-Encoder is OFF	After a STOP or an inversion command given during the closing, the gate recovers the excess space traveled by inertia	ALL	It depends on motor	
72	OPENING TOLERANCE MOTOR 1	0% 100% (*)	To adjust the tolerance space between the recognition of the mechanical stop in opening and the recognition of the obstacle - In case of obstacle within the tolerance space, this will be considered as mechanical stop	ALL	20%	
73	CLOSING TOLERANCE MOTOR 1	0% 100% (*)	To adjust the tolerance space between the recognition of the mechanical stop in closing and the recognition of the obstacle - In case of obstacle within the tolerance space, this will be considered as mechanical stop	ALL	20%	
74	OPENING TOLERANCE MOTOR 2	0% 100% (*)	To adjust the tolerance space between the recognition of the mechanical stop in opening and the recognition of the obstacle - In case of obstacle within the tolerance space, this will be considered as mechanical stop	ALL	20%	
75	CLOSING TOLERANCE MOTOR 2	0% 100% (*)	To adjust the tolerance space between the recognition of the mechanical stop in closing and the recognition of the obstacle - In case of obstacle within the tolerance space, this will be considered as mechanical stop	ALL	20%	
* With «RT» Encoder: 0% = 20 impulses 100% = 200 impulses With «POSITION GATE» : 0% = 20 impulses 100% = 500 impulses						
76	PUSHING STROKE	Time Pushing Off - 3 sec Stroke	Before opening, the motor starts up in closing for the time set, in order to simplify the lock release	ALL	Off	
		Repeat Lock Release Off - On	If ON, the lock will be released both before and after the pushing stroke			
		End				
77	LOCK TIME	Off 5 seconds	To adjust the lock release time from 0 to 5 seconds	ALL	3 s	
78	LOCK	Only opening	To enable the lock only before opening	ALL	Only opening	
		Only closing	To enable the lock only before closing			
		Opening and closing	To enable the lock before both opening and closing			
79	ANTI INTRUSION	Only opening	If the gate moves, whether due to wind or manual forcing, the function starts up the operator to restore the initial position. (function available only if limit switch or potentiometer or «RT» encoder are installed)	ALL	Off	
		Only closing				
		Opening and closing				
		Off				
80	PUSHOVER	Off	The gate leaf makes an extra movement at the maximum torque to ensure the tightening of the gate In case of a STOP command, the Pushover function is restored only after a new START command	ALL	Off	
		Opening and closing				
		Only closing				
		Only opening				
81	PERIODIC PUSHOVER	Off 8h If the pushover is enabled	To enable the the pushover function repetition at a time distance adjustable from 0 to 8 hours, at hourly intervals	ALL	Off	
82	MOTOR RELEASE	Opening 1 Off - 3 s	If different than OFF, the motor slightly reverses the rotation direction for the set time (up to 3 seconds) at the end of the cycle	ALL	It depends on motor	
		Closing 1 Off - 3 s				
		Opening 2 Off - 3 s				
		Closing 2 Off - 3 s				
		End				
83	EXTRA TIME	Opening 1 Off - 10 s	If the limit switches are installed, it is possible to add an extra time (max. 10 seconds) to the movement of the operators after the reading of the limit switches; Note: if the Encoder is installed, the space can be set by impulses (from 0 to 100)	INVERTER 24V BR	1.0 s	
		Closing 1 Off - 10 s				
		Opening 2 Off - 10 s				
		Closing 2 Off - 10 s				
		EXIT				
		0.0 s 10 s		2PM		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
85	PRE-FLASHING	Only closing	To enable the pre-flashing only before closing (To access this option: press DOWN when 0.0 is displayed)	ALL	0.0 s	
		0.0 5.0 s	To set the pre-flashing duration			
86	FLASHING LIGHT	Normal	Normal	ALL	Normal	
		Light	Warning lamp function			
		Always	Always ON			
		Buzzer	Buzzer			
87	FLASHING LIGHT AND TIMER	Off	The flashing light will be OFF with enabled timer and open gate	ALL	Off	
		On	The flashing light will be ON with enabled timer and open gate			
88	COURTESY LIGHT	Off	Disabled	ALL	In cycle	
		1 240	Adjustable from 1 second to 4 minutes			
		In cycle	Courtesy light only in cycle			
89	TRAFFIC LIGHT RESERVATION	Off On	To get the priority in entry (via a START command) or in exit (via a PARTIAL START command). The function is available only if a traffic light is wired	ALL	Off	
90	PARTIAL OPENING	5% 100%	Adjustable from 5% to 100%	ALL	50%	
91	PARTIAL PAUSE	= START	The pause in partial opening is the same as in total opening	ALL	= START	
		Off	Disabled			
		1 240	Adjustable from 1 second to 4 minutes			
92	TIMER	Off	To turn the selected input into an input to which an external clock can be connected	ALL	Off	
		On Photocell 2				
		On Partial START				
		Clock				
93	FIRE SWITCH	Off	Disabled	ALL	Off	
		On Photocell 2	The function can be enabled on the Photocell 2 input			
		On Partial START	The function can be enabled on the Partial START input			
94	24V AUX (Max. 1 A) The AUX output allows the wiring of additional accessories via relay; accessories will work according to the chosen option	Always	AUX output always powered	ALL	Always	
		In cycle	AUX output powered only during cycle			
		Opening	AUX output powered only during opening			
		Closing	AUX output powered only during closing			
		In pause	AUX output powered only during pause			
		Phototest	AUX output powered for safety devices testing			
		In cycle and phototest	AUX output powered during cycle only and for safety devices testing			
		In cycle and pause	AUX output powered during cycle and during pause			
		Courtesy light	To enable an additional courtesy light wired via external relay. The courtesy light will work according to the settings of the menu 88 - COURTESY LIGHT			
		Barrier and Bollard LED lights	Closed operator - the light is switched-on Open operator - the light is switched-off Moving operator - the light blinks			
		Open gate warning light	1 flash per second - during opening 2 flashes per second - during closing Steady lit - gate in «STOP» or «OPEN» status			
		Fan	AUX output powered during cycle and for 2 additional minutes after the end of the cycle ie.: a cooling fan connected via relay	INVERTER		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
95	PHOTO-TEST	Photocell 1	Self-test enabled only on photocell 1	ALL	Off	
		Photocell 2	Self-test enabled only on photocell 2			
		Photocells 1 and 2	Self-test enabled on photocells 1 and 2			
		Off	Disabled			
96	SAFETY EDGE SELF-TEST	Safety Edge 1	Self-test enabled only on safety edge 1	ALL	Off	
		Safety Edge 2	Self-test enabled only on safety edge 2			
		Safety Edges 1 and 2	Self-test enabled on safety edges 1 and 2			
		Off	Disabled			
97	PHOTOCELL 1	Closing	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Closing	
		Opening and closing	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		STOP	If the photocell is occupied before the START input, the START will be ignored. If the photocell is occupied after the START input, the photocell will be ignored. If the photocell is occupied during closing, the gate will reopen			
		STOP and close	If the photocell is occupied during closing, it stops the gate movement; when released, the closing movement continues			
		Close	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command (the gate closes one second after the photocell release)			
		Closing Pause reloading	If the photocell is occupied during the pause, it reloads the same pause time set. If the photocell is occupied in closing, it reverses the gate movement			
		Opening and Closing Pause reloading	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during the closing, it reverses the gate movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening movement continues			
		Shadow loop *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		Delete pause time	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
		Shadow loop PR (pause reloading) *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing			
* If the module 2PM is in use, the shadow loop does not enable when the menu-121 is set to «Photo 1 10K»						

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
98	PHOTOCELL 2	Closing	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Opening and closing	
		Opening and closing	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		STOP	If the photocell is occupied before the START input, the START will be ignored. If the photocell is occupied after the START input, the photocell will be ignored. If the photocell is occupied during closing, the gate reopens			
		STOP and close	If the photocell is occupied during closing, it stops the gate; when released, the closing movement continues			
		Close	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command (the gate closes one second after the photocell release)			
		Opening Pause reloading	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied during the opening, the gate stops and when released, the movement continues			
		Pause reload Photo closing	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during closing, the gate reverses the movement			
		Opening and Closing Pause reloading	If the photocell is occupied during the pause, it reloads the pause time set. If the photocell is occupied during the closing, it reverses the movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening continues			
		Shadow loop *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		Delete pause time	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
		Shadow loop PR (pause reloading) *	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing			
		STOP and open	If the photocell is occupied during opening, the gate stops; when released, the gate continues the opening movement. The photocell is ignored during closing			
* If the module 2PM is in use, the shadow loop does not enable when the menu-121 is set to «Photo 1 10K»						
99	PHOTO OFF IN CLOSING	0% 50%	In closing, this function excludes the photocell reading for the space percentage set	INVERTER 24V	0%	
100	SAFETY EDGE 1	Normal	Standard safety edge - N.C. contact	ALL	Normal	
		8K2 N.C.	Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double	Two safety edges protected by 8K2 resistor enabled			
		8K2 RES	Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double	Two resistive edges protected by 8K2 RES enabled			
101	SAFETY EDGE 2	Normal	Standard safety edge - N.C. contact	ALL	Normal	
		8K2 N.C.	Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double	Two safety edges protected by 8K2 resistor enabled			
		8K2 RES	Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double	Two resistive edges protected by 8K2 RES enabled			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
102	SAFETY EDGE 1 DIRECTION	Opening and closing	Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening	Safety edge enabled only in opening			
		Only closing	Safety edge enabled only in closing			
103	SAFETY EDGE 2 DIRECTION	Opening and closing	Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening	Safety edge enabled only in opening			
		Only closing	Safety edge enabled only in closing			
104	SELECT LIMIT SWITCH	N. C.	Limit switch type N.C. (Normally Closed) Example: inductive limit switch or with lever	INVERTER 24V	N.C.	
		Ext	Limit switch connected on the external interface for 4 cams limit switches			
		N.O.	Limit switch type N.O. (Normally Open) Example: magnetic limit switch			
		Automatic	Automatic detection of the limit switch	2PM	Automatic	
		Opening only	Limit switch enabled only in opening			
		Closing only	Limit switch enabled only in closing			
		Ext	Limit switch connected on the external interface for 4 cams limit switches			
		Motor internal	To be enabled if the operator is equipped with an inner limit switch that stops the motor phase			
105	PRIMARY/SECONDARY (MASTER/SLAVE)	Primary	To set the control unit as PRIMARY on applications with two operators in primary/secondary mode	INVERTER BR	Off	
		Secondary	To set the control unit as SECONDARY on applications with two operators in primary/secondary mode			
		Off	Disabled			
106	DIAGNOSTICS	1 10	To display the last 10 events (alarms) (See Chapter «ALARMS»)	ALL	----	
107	MAINTENANCE CYCLES	100 240000	Adjustable from 100 to 240000 cycles	ALL	100000	
108	PERFORMED CYCLES	0 240000	To display the executed cycles. Hold pressed OK to reset the cycles	ALL	0	
109	THERMOMETER *	xx °C (xx °C)	To display the temperature if a probe is connected. The connection of up to two temperature probes is allowed; in this case, the display will show both temperatures detected	INVERTER 24V 2PM	Off	
110	LOWER TEMPERATURE THRESHOLD *	From -20° to +50°	To adjust the temperature threshold to enable the oil heater	INVERTER 24V 2PM	-10°	
111	UPPER TEMPERATURE THRESHOLD *	From -20° to +50°	To adjust the temperature threshold to disable the oil heater	INVERTER 24V 2PM	0°	
* The menus are shown only if one or two temperature probes are connected to the GP1 and/or GP2 inputs and if the respective menus 130-GP1 and/or 131-GP2 are set to «THERMOMETER»						
112	PASSWORD	Note: «0000» setting is not allowed	To enter a password for blocking the control unit parameters modification	ALL	----	

SPECIAL MENU		SET		DESCRIPTION	MODEL	DEFAULT	NOTE
113	EMERGENCY	Off		Disabled	ALL	Off	
		Emergency		In case of power failure and with batteries connected and charged, the gate opens completely and remains open until the power is restored			
		Last opening		In case of power failure, as soon as the battery charge drops below 22V, the gate opens one last time and remains open until the power is restored			
		Last closing		In case of power failure, as soon as the battery charge drops below 22V, the gate closes one last time and remains closed until the power is restored			
115	DECELERATION RAMP	0,1 s	5s	Deceleration management in case of inversion or STOP command	INVERTER 24V - BR	0,5 s	
116	REPEAT LEAF DELAY	On	Off	In case of a STOP command when the gate is on its halfway, the leaves will repeat the «leaf delay» set on menus 26-27	ALL	On	
117	ALWAYS CLOSE	Off	240 seconds	In case of power failure, if the gate has been manually open, it closes only after the set time has elapsed (from 0 to 240 seconds) as soon as the power is restored	ALL	Off	
118	LATCH	Off		Disabled	ALL	Off	
		Opening		To enable the LATCH button wired to the «Safety Edge 1» N.O. input (Safety Edge 1 will be disabled); after a LATCH button command the gate opens and stay open till a new LATCH button command			
		Closing		To enable the LATCH button wired to the «Safety Edge 2» N.O. input (Safety Edge 2 will be disabled); after a LATCH button command the gate closes and stay closed till a new LATCH button command			
		Opening and closing		To enable the LATCH buttons wired to the «Safety Edge 1» and «Safety Edge 2» N.O. inputs (both Safety Edges will be disabled); The two LATCH buttons can be used as above described			
To disable the LATCH, press one more time the same button used to enable The LATCH command can also be sent from Tx or SEACLOUD, thus keeping the SAFETY EDGE inputs free							
119	DISPLAY WRITING SPEED	From 30% to 100%		The scrolling speed of the text can be adjusted from 30% to 100%	INVERTER 24V 2PM	80%	
If the menu 119 is set to the minimum value of 30%, the scrolling speed will be low. On the contrary, if adjusted to the maximum value of 100%, the scrolling speed of the text will be very high. Note: the speed does not change on the display of the JOLLY 3 programmer!							
120	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes					
121	PHOTO 1 TYPE	Normal		Standard photocell without 10K control	ALL	Normal	
		Photo 1 10K		Photocell with 10K control			
		Photo 1 10K DOUBLE		Double photocell with 10K control	2PM		
122	PHOTO 2 TYPE	Normal		Standard photocell without 10K control	ALL	Normal	
		Photo 2 10K		Photocell with 10K control			
		Photo 2 10K DOUBLE		Double photocell with 10K control	2PM		
123	DATE AND TIME	Mon - Sun dd/mm/yyyy Time		To set the day, the date and the time for the management of the programmed openings. (Only with full charge buffer battery)	ALL	----	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
124	CLOCK 1	Opening time	To set a first time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
125	CLOCK 2	Opening time	To set a second time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
126	CLOCK 3	Opening time	To set a third time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
127	CLOCK 4	Opening time	To set a fourth time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
130	GP1	Off	Disabled	ALL	Off	
		Open	To enable an opening button wired to GP1; the button will operate in «Dead Man» logic and will only work when the gate is closed or after a STOP command			
		Emergency open	To enable an emergency opening button wired to GP1; the button will operate in «Dead Man» logic and will only work in case of safety devices failure or in case of stuck START button			
		Thermometer	To enable the temperature probe wired to the GP1 input (to detect hydraulic motors oil temperature). The menu 109 displays the detected value	INVERTER 24V 2PM		
		Cage	To control the Motor 1 only if the Motor 2 is closed			
131	GP2	Off	Disabled	ALL	Off	
		Close	To enable a closing button wired to GP2; the button will operate in «Dead Man» logic and will only work when the gate is open or after a STOP command			
		Emergency close	To enable an emergency closing button wired to GP2; the button will operate in «Dead Man» logic and will only work in case of safety devices failure or in case of stuck START button			
		Thermometer	To enable the temperature probe wired to the GP2 input (to detect hydraulic motors oil temperature). The menu 109 displays the detected value	INVERTER 24V 2PM		
		Cage	To control the Motor 2 only if the Motor 1 is closed			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
132	RELAY 1	Off	Disabled	ALL	Off	
		START 3s	To enable the Relay 1 for 3 seconds at every START or reopening command			
		Traffic light	The Relay 1 manages the wired traffic light as follows: The green light is switched-on only when the gate is open. The red light is switched-on when the gate is moving or closed			
		Entry traffic light	This option allows to acquire the <u>priority in entry</u> by sending a START command - <i>Thus, the exit traffic light turns red.</i> This function can be enabled only if menu 89-TRAFFIC LIGHT RESERVATION is set to ON			
		Exit traffic light	This option allows to acquire the <u>priority in exit</u> by sending a PARTIAL START command - <i>Thus, the entry traffic light turns red.</i> This function can be enabled only if menu 89-TRAFFIC LIGHT RESERVATION is set to ON			
		Lock copy	If a lock is wired via relay, this option replicates the management settings given to the menu 78-LOCK			
		Flashing light copy	If a flashing light is wired via relay, this option replicates the management settings given to the menu 86-FLASHING LIGHT			
		Courtesy light copy	If a courtesy light is wired via relay, this option replicates the management settings given to the menu 88-COURTESY LIGHT			
		Fire-switch copy	If a fire-switch is wired via relay, this option replicates the management settings given to the menu 93-FIRE SWITCH			
		Opening 1 limit switch	The Relay 2 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in «OPEN» status			
		Closing 1 limit switch	The Relay 2 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in «CLOSED» status			
		Opening 2 limit switch	The Relay 2 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in «OPEN» status			
		Closing 2 limit switch	The Relay 2 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in «CLOSED» status			
		Tx Relay	If the function «RELAY 1» has been stored on the transmitter second channel, the Relay 1 can be activated for 3 seconds by pressing the Tx button. Example: to turn on a courtesy light wired via relay			
		Negative brake and Photocell management	Negative electric brake the Relay is enabled when the gate is in cycle and 1 second before the start up. The photocell intervention disables the relay			
		Negative brake management	Negative electric brake the Relay is enabled when the gate is in cycle and 1 second before the start up			
		Positive brake management	Positive electric brake the Relay is enabled when the gate is stationary			
		Opening electric-valve	To enable the operation in opening of the electric valve wired via Relay 1			
		Closing electric-valve	To enable the operation in closing of the electric valve wired via Relay 1			
		Clock 1 and 2	The Relay will be active in the same time band set on menus 124 and 125			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
133	RELAY 2	Off	Disabled	ALL	Off	
		START 3s	To enable the Relay 2 for 3 seconds at every START or reopening command			
		Traffic light	The Relay 2 manages the wired traffic light as follows: The green light is switched-on only when the gate is open. The red light is switched-on when the gate is moving or closed			
		Entry traffic light	This option allows to acquire the <u>priority in entry</u> by sending a START command - <i>Thus, the exit traffic light turns red.</i> This function can be enabled only if menu 89-TRAFFIC LIGHT RESERVATION is set to ON			
		Exit traffic light	This option allows to acquire the <u>priority in exit</u> by sending a PARTIAL START command - <i>Thus, the entry traffic light turns red.</i> This function can be enabled only if menu 89-TRAFFIC LIGHT RESERVATION is set to ON			
		Lock copy	If a lock is wired via relay, this option replicates the management settings given to the menu 78-LOCK			
		Flashing light copy	If a flashing light is wired via relay, this option replicates the management settings given to the menu 86-FLASHING LIGHT			
		Courtesy light copy	If a courtesy light is wired via relay, this option replicates the management settings given to the menu 88-COURTESY LIGHT			
		Fire-switch copy	If a fire-switch is wired via relay, this option replicates the management settings given to the menu 93-FIRE SWITCH			
		Opening 1 limit switch	The Relay 2 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in «OPEN» status			
		Closing 1 limit switch	The Relay 2 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in «CLOSED» status			
		Opening 2 limit switch	The Relay 2 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in «OPEN» status			
		Closing 2 limit switch	The Relay 2 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in «CLOSED» status			
		Tx Relay	If the function «RELAY 2» has been stored on the transmitter second channel, the Relay 2 can be activated for 3 seconds by pressing the Tx button. Example: to turn on a courtesy light wired via relay			
		Negative brake and Photocell management	Negative electric brake the Relay is enabled when the gate is in cycle and 1 second before the start up. The photocell intervention disables the relay			
		Negative brake management	Negative electric brake the Relay is enabled when the gate is in cycle and 1 second before the start up			
		Positive brake management	Positive electric brake the Relay is enabled when the gate is stationary			
		Opening electric-valve	To enable the operation in opening of the electric valve wired via Relay 2			
		Closing electric-valve	To enable the operation in closing of the electric valve wired via Relay 2			
		Clock 3 and 4	The relay will be active in the same time band set on menus 126 and 127			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
134	RELAY FV 1 (Relay on the FV MODULE 1)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric brake the Relay FV1 is enabled when the gate is stationary			
		Negative brake management	Negative electric brake the Relay FV1 is enabled when the gate is in cycle or 1 second before the start up or in case of photocell intervention			
		Negative brake management and Photocell	Negative electric brake the Relay FV1 is enabled when the gate is in cycle and 1 second before the start up. The photocell intervention disables the Relay FV1			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 1 will enable only if the gate is closed			
		Copy START	The Relay FV 1 will enable at every START command			
135	RELAY FV 2 (Relay on the FV MODULE 2)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric brake the Relay FV2 is enabled when the gate is stationary			
		Negative brake management	Negative electric brake the Relay FV2 is enabled when the gate is in cycle or 1 second before the start up or in case of photocell intervention			
		Negative brake management and Photocell	Negative electric brake the Relay FV2 is enabled when the gate is in cycle and 1 second before the start up. The photocell intervention disables the Relay FV2			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 2 will enable only if the gate is closed			
		Copy START	The Relay FV 2 will enable at every START command			
136	EFO	0% 100%	This menu will be shown only if the menu 3-MOTORS is set to «5-Threephase/Bollards» This function allows the emergency closing with a higher speed than the set percentage and without considering the safety devices connected. It works only with BOLLARDS and through a command button wired on the PARTIAL START input	INVERTER	50%	
137	COMIS	0 350 mA	To display the absorption of the 24V accessories wired to clamps 19 (24Vdc+) and 20 (COMMON ACCESSORIES) of CN2 terminal, up to a maximum load of 350 mA	ALL	----	
138	COMIS THRESHOLD	Off 350mA	To set a maximum absorption threshold, beyond which an error message appears. In any case, the error message also appears if 350 mA is exceeded	ALL	Off	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
140	THRESHOLD A OPENING 1	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 1 in opening (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
141	THRESHOLD A CLOSING 1	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 1 in closing (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
142	THRESHOLD A OPENING 2	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 2 in opening (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
143	THRESHOLD A CLOSING 2	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 2 in closing (over the set threshold the motor will detect an obstacle)	INVERTER	It depends on motor	
144	THRESHOLD A OPENING SLOWDOWN 1	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 1 in slowdown during opening	INVERTER	It depends on motor	
145	THRESHOLD A CLOSING SLOWDOWN 1	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 1 in slowdown during closing	INVERTER	It depends on motor	
146	THRESHOLD A OPENING SLOWDOWN 2	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 2 in slowdown during opening	INVERTER	It depends on motor	
147	THRESHOLD A CLOSING SLOWDOWN 2	0,1 10 Ampere	To adjust the amperometric intervention threshold of motor 2 in slowdown during closing	INVERTER	It depends on motor	
190	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes				

PART FOR BOTH INSTALLER AND END-USER

MAINTENANCE: periodically, it would be advisable to reprogram the working times on the control unit according to the number of cycles performed over time and according to the type of operator, especially if changes in friction, malfunctions or non-compliance with the previously set working times are noticed. Periodically clean the optical system of the photocells.

SAFETY PRECAUTIONS: all electrical works and the choice of the operating logic should comply with the current regulations. A 16A/0,030 differential switch must be used. Separate the source cables (*operators, power supply*) and command cables (*photocells, push-buttons, etc*). Be sure the system is properly grounded. Always run cables in separate sheaths to prevent interferences

SPARE PARTS: send request for spare parts to: **SEA S.p.A. - Teramo - ITALY - www.seateam.com**

SAFETY AND ENVIRONMENTAL COMPATIBILITY: do not waste product packaging materials and/or circuits; do not dispose of the product with other domestic waste at the end of its life cycle. In order to avoid any possible environmental or health damage caused by irregular waste disposal, we recommend to separate this product from other types of waste and to recycle it in a responsible way in order to provide the sustainable re-use of material resources. Domestic users are invited to contact the retailer where the product has been purchased or the local office to get all the information related to differential waste collection and recycling of this kind of product.

STORAGE: T = -30°C/+60°C ; Humidity = min. 5% / max. 90% (without condensation); Materials must be properly packaged, handled with care and with appropriate vehicles

WARRANTY LIMITS: - see the sales conditions

MAINTENANCE AND DECOMMISSION: must be carried out only by specialized and authorized personnel

THE MANUFACTURER CAN NOT BE DEEMED RESPONSIBLE FOR ANY DAMAGE OR INJURY CAUSED BY IMPROPER USE OF THIS PRODUCT

SEA S.p.A. reserves the right to make any required modification or change to the products and/or to this manual without any advanced notice obligation.

GENERAL NOTICE

1. Read carefully these instructions before beginning to install the product. Store these instructions for future reference
2. Don't waste product packaging materials and /or circuits
3. This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger. SEA S.p.A. declines all liability caused by improper use or different use in respect to the intended one.
4. The mechanical parts must comply with Directives: Machine Regulation 2006/42/CE and following adjustments, Low Tension (2006/95/CE), Electromagnetic Consistency (2004/108/CE); Installation must respect Directives: EN12453 and EN12445.
5. Do not install the equipment in an explosive atmosphere.
6. SEA S.p.A. is not responsible for failure to observe Good Techniques in the construction of the locking elements to motorize or for any deformation that may occur during use
7. Before attempting any job on the system, cut out electrical power and disconnect the batteries. Be sure that the grounding system is perfectly constructed, and connect to it the metal parts of the gate
8. Use of the indicator-light is recommended for every system, as well as a warning sign well-fixed to the frame structure.
9. SEA S.p.A. declines all liability concerning the automated system safety and efficiency, if components used are not produced by SEA
10. For maintenance, strictly use original parts by SEA.
11. Do not modify in any way the components of the automated system.
12. The installer shall supply all information concerning the system manual functioning in case of emergency and shall hand over to the user the warnings handbook supplied with the product.
13. Do not allow children or adults to stay near the product while it is operating. The application cannot be used by children, by people with reduced physical, mental or sensorial capacity or by people without experience or necessary training. Keep remote controls or other pulse generators away from children, to prevent involuntary activation of the system.
14. Transit through the leaves is allowed only when the gate is fully open.
15. The User must not attempt to repair or to take direct action on the system and must solely contact qualified SEA personnel or SEA service centers. The User can apply only the manual function of emergency.
16. The power cables maximum length between the central engine and motors should not be greater than 10 m. Use cables with 2,5 mm² section. Use double insulation cable (cable sheath) to the immediate vicinity of the terminals, in particular for the 230V cable. Keep an adequate distance (at least 2.5 mm in air), between the conductors in low voltage (230V) and the conductors in safety low voltage (SELV) or use an appropriate sheath that provides extra insulation having a thickness of 1 mm

TERMS OF SALE

EFFICACY OF THE FOLLOWING TERMS OF SALE: the following general terms of sale shall be applied to all orders sent to SEA S.p.A. All sales made by SEA to all customers are made under the prescription of this terms of sales which are integral part of sale contract and cancel and substitute all apposed clauses or specific negotiations present in order document received from the buyer.

GENERAL NOTICE The systems must be assembled exclusively with SEA components, unless specific agreements apply. Non-compliance with the applicable safety standards (European Standards EN12453 – EN 12445) and with good installation practice releases SEA from any responsibilities. SEA shall not be held responsible for any failure to execute a correct and safe installation under the above mentioned standards.

1) PROPOSED ORDER The proposed order shall be accepted only prior SEA approval of it. By signing the proposed order, the Buyer shall be bound to enter a purchase agreement, according to the specifications stated in the proposed order. On the other hand, failure to notify the Buyer of said approval must not be construed as automatic acceptance on the part of SEA.

2) PERIOD OF THE OFFER The offer proposed by SEA or by its branch sales department shall be valid for 30 solar days, unless otherwise notified.

3) PRICING The prices in the proposed order are quoted from the Price List which is valid on the date the order was issued. The discounts granted by the branch sales department of SEA shall apply only prior to acceptance on the part of SEA. The prices are for merchandise delivered ex-works from the SEA establishment in Teramo, not including VAT and special packaging. SEA reserves the right to change at any time this price list, providing timely notice to the sales network. The special sales conditions with extra discount on quantity basis (Qx, Qx1, Qx2, Qx3 formula) is reserved to official distributors under SEA management written agreement.

4) PAYMENTS The accepted forms of payment are each time notified or approved by SEA. The interest rate on delay in payment shall be 1.5% every month but anyway shall not be higher than the max. interest rate legally permitted.

5) DELIVERY shall take place, approximately and not peremptorily, within 30 working days from the date of receipt of the order, unless otherwise notified. Transport of the goods shall be at Buyer's cost and risk. SEA shall not bear the costs of delivery giving the goods to the carrier, as chosen either by SEA or by the Buyer. Any loss or damage of the goods during transport, are at Buyer's cost

6) COMPLAINTS Any complaints or claims shall be sent to SEA within 8 solar days from receipt of the goods, proved by adequate supporting documents as to their truthfulness

7) SUPPLY The concerning order will be accepted by SEA without any engagement and subordinately to the possibility to get its supplies of raw material which is necessary for the production; Eventual completely or partially unsuccessful executions cannot be reason for complaints or reservations for damage. SEA supply is strictly limited to the goods of its manufacturing, not including assembly, installation and testing. SEA, therefore, disclaims any responsibility for damage deriving, also to third parties, from non-compliance of safety standards and good practice during installation and use of the purchased products.

8) WARRANTY The standard warranty period is 12 months. This warranty time can be extended by means of expedition of the warranty coupon as follows:

SILVER: The mechanical components of the operators belonging to this line are guaranteed for 24 months from the date of manufacturing written on the operator.

GOLD: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator.

PLATINUM: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator. The base warranty (36 months) will be extended for further 24 months (up to a total of 60 months) when it is acquired the certificate of warranty which will be filled in and sent to SEA S.p.A. The electronic devices and the systems of command are guaranteed for 24 months from the date of manufacturing. In case of defective product, SEA undertakes to replace free of charge or to repair the goods provided that they are returned to SEA repair centre. The definition of warranty status is by unquestionable assessment of SEA. The replaced parts shall remain propriety of SEA. Binding upon the parties, the material held in warranty by the Buyer, must be sent back to SEA repair centre with fees prepaid, and shall be dispatched by SEA with carriage forward. The warranty shall not cover any required labour activities. The recognized defects, whatever their nature, shall not produce any responsibility and/or damage claim on the part of the Buyer against SEA. The guarantee is in no case recognized if changes are made to the goods, or in the case of improper use, or in the case of tampering or improper assembly, or if the label affixed by the manufacturer has been removed including the SEA registered trademark No. 804888. Furthermore, the warranty shall not apply if SEA products are partly or completely coupled with non-original mechanical and/or electronic components, and in particular, without a specific relevant authorization, and if the Buyer is not making regular payments. The warranty shall not cover damage caused by transport, expendable material, faults due to non-conformity with performance specifications of the products shown in the price list. No indemnification is granted during repairing and/or replacing of the goods in warranty. SEA disclaims any responsibility for damage to objects and persons deriving from non-compliance with safety standards, installation instructions or use of sold goods. The repair of products under warranty and out of warranty is subject to compliance with the procedures notified by SEA

9) RESERVED DOMAIN A clause of reserved domain applies to the sold goods; SEA shall decide autonomously whether to make use of it or not, whereby the Buyer purchases property of the goods only after full payment of the latter.

10) COMPETENT COURT OF LAW In case of disputes arising from the application of the agreement, the competent court of law is the tribunal of Teramo. SEA reserves the faculty to make technical changes to improve its own products, which are not in this price list at any moment and without notice. SEA declines any responsibility due to possible mistakes contained inside the present price list caused by printing and/or copying. The present price list cancels and substitutes the previous ones. The Buyer, according to the Law No. 196/2003 (privacy code) consents to put his personal data, deriving from the present contract, in SEA archives and electronic files, and he also gives his consent to their treatment for commercial and administrative purposes.

Industrial ownership rights: once the Buyer has recognized that SEA has the exclusive legal ownership of the registered SEA brand num.804888 affixed on product labels and/or on manuals and/or on any other documentation, he will commit himself to use it in a way which does not reduce the value of these rights, he won't also remove, replace or modify brands or any other particularity from the products. Any kind of replication or use of SEA brand is forbidden as well as of any particularity on the products, unless preventive and expressed authorization by SEA. **In accomplishment with art.1341 of the Italian Civil Law it will be approved expressly clauses under numbers: 4) PAYMENTS - 8) GUARANTEE - 10) COMPETENT COURT OF LAW**

DECLARATION OF CONFORMITY

DICHIARAZIONE DI CONFORMITÀ

SEA S.p.A. declares under its proper responsibility and, if applicable, under the responsibility of its authorised representative that, by installing the appropriate safety equipment and noise filtering, the products:

La SEA S.p.A. dichiara sotto la propria responsabilità e, se applicabile, del suo rappresentante autorizzato che, con l'installazione degli adeguati dispositivi di sicurezza e di filtraggio disturbi, i prodotti:

DESCRIPTION - DESCRIZIONE	MODEL - MODELLO	TRADEMARK - MARCA
UNIGATE 2-I (AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)	23023060	SEA
UNIGATE 1-I BIG (AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)	23023065	SEA
UNIGATE 2 PM (AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)	23023050	SEA
UNIGATE 24V (AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)	23024130	SEA
UNIGATE BR (AND ALL ITS BY-PRODUCTS - E TUTTI I SUOI DERIVATI)	23023092	SEA

- are built to be integrated into a machine or to be assembled with other machinery to create a machine under the provisions of Directive 2006/42/CE;

- comply with the essential safety requirements related to the products within the field of applicability of the Community Directives 2014/35/UE and 2014/30/UE

- sono costruiti per essere incorporati in una macchina o per essere assemblati con altri macchinari per costruire una macchina ai sensi della Direttiva 2006/42/CE;

- sono conformi ai requisiti essenziali di sicurezza relativi ai prodotti entro il campo di applicabilità delle Direttive Comunitarie 2014/35/UE e 2014/30/UE

PLACE AND DATE OF ISSUE
LUOGO E DATA DI EMISSIONE

TERAMO, 06/09/2022

THE MANUFACTURER OR THE AUTHORIZED REPRESENTATIVE
IL COSTRUTTORE o IL RAPPRESENTANTE AUTORIZZATO

SEA S.p.A.
ZONA INDUSTRIALE SANT'ATTO
64100 - TERAMO - ITALY
+ 39 0 861 588341
www.seateam.com

L'Amministratore
The Administrator
Ennio Di Saverio




SEA®



Automatic Gate Openers

International registered trademark n. 804888

SEA S.p.A.

Zona Industriale Sant'Atto - 64100 - Teramo - ITALY

Tel. +39 0 861 588341 r.a.

www.seateam.com